




External Antenna Installation Notes:

1. Drill the hole for the bulkhead adapter in the **BOTTOM** of the enclosure **ONLY**.
2. The hole dimension is 5/8".
3. Use coaxial staples, to secure the cable to wooden poles.
4. Create a loop in the cable at the antenna to allow for antenna movement.
5. Create a loop in the cable at the box to allow water to drip off the cable.

**Only drill hole in
bottom of Enclosure**



Antenna & Mount Example

