

This manual is for educational purposes only. The accuracy and completeness of the information provided herein is not guaranteed or warranted. Genave shall not be liable for any loss or damages. Use at your own risk. Unauthorized reproduction is prohibited. Copyright © 2007 Genave/NRC, Inc., all rights reserved.

other quality electronic products
engineered by Genave for general
use at moderate prices

Aviation:

Alpha/600
All transistor Nav/Com

Beta/5000
TSOD ATC Transponder

Sigma/1500
Digital ADF

Delta/303
Marker Beacon Receiver

Marine:

Marine/Mate-10
10 watt Marine R/T

Marine/Gain-50
3 db gain Marine antenna

Marine/Gain-100
6 db gain Marine antenna

Marine/Gain-50M
3 db gain Sailboat antenna

Amateur:

GTX-10
2-Meter FM
10 watt output, rotary channel selector

GTX-2
2-Meter FM
30 watt output, pushbutton channel selection

GTX-200
2-Meter FM
30 watt output, independent Xmit & receive

MANUFACTURED IN THE UNITED STATES

marine division




GENERAL AVIATION ELECTRONICS, INC.

4141 Kingman Drive
Indianapolis, Indiana 46226
AREA (317) 546-1111

Specifications subject to change without notice.

© Copyright, March 1974, General Aviation Electronics, Inc. All Rights Reserved.

**MAINTENANCE
MANUAL**



Marine/Master-25W & 25WA

This manual is for educational purposes only. The accuracy and completeness of the information provided herein is not guaranteed or warranted. Genave shall not be liable for any loss or damages. Use at your own risk. Unauthorized reproduction is prohibited. Copyright © 2007 Genave/NRC, Inc. All rights reserved.

Price
\$2.00

Warranty

General Aviation Electronics, Inc., warrants this product to be free from material defects for a period of 90 days from the date of purchase.

Our obligation under this warranty is to replace any parts (except service items such as bulbs, fuses, etc.) which upon our examination appear to us to be defective in materials or workmanship, with any labor charges involved at the cost of the owner, provided the unit is delivered to the Factory within the specified time period.


The owner may elect to have the unit repaired at an authorized Genave dealer, in which case Genave will replace only those defective parts returned shipping pre-paid to the Factory, and will not be responsible in any way for payment of any labor or other charges incurred therein.

This warranty does not apply to defects, malfunction, or breakage due to improper installation or to the servicing thereof by other than an authorized Genave dealer, or due to abuse, misuse, tampering, submer- sion in water or willful destruction of the unit.

The Company offers no other guarantees or warranties expressed or implied.

The Marine/Master-25w was under strict quality control during its fabrication and was thoroughly checked by skilled technicians prior to shipment. With reasonable care and handling it will provide years of satisfactory operation.

Marine/Master-25w comes ready to be installed and does not require installation by a licensed FCC technician. The Marine/Master-25w was designed with the installation simplicity which makes it a "natural" for installation.



Panel Design by Jon Hansen

Specifications:

GENERAL:

Front Panel Size:
Over-all Dimensions:
Number of Transistors:

Power Supply:
Current Drain:

Frequency Range:
Number of Channels:

Weight:

RECEIVE:

Sensitivity:
Image:
Spurious:
Selectivity:
Receiver Circuit:

Audio Output:
Modulation Acceptance:
Squelch Threshold:

TRANSMIT:

Frequency Range:
Power Output:
Output Impedance:
Deviation:

6 1/2" x 2 1/2"
9" deep x 6 1/2" wide x 2 1/2" high
11 all silicon transistors, 4 diodes,
5 FETs, 3 integrated circuits
12 VDC System, negative ground
Receive .09 amps
Transmit: High 5.0 amps
LOW 1.7 amps
144 to 148 MHz
10 (includes 146, 940 MHz. Remaining 9
frequencies, at nominal charge each for
installation at factory or by owner.)
5-lbs. (approx.)

less than 0.5 microvolts for 12 db SINAD
More than 45 db
More than 50 db
+ 8 KHz
Double conversion, superheterodyne,
crystal controlled
1.5 watts at less than 15% distortion
More than 7.5 KHz
0.5 microvolt max.

144 to 148 MHz
30 watts, Nom
Matches standard 50 ohm amateur antennas
Adjustable to 10 KHz max.

ABOUT VHF-FM

The Marine/Master-25w is designed to replace the old Medium Frequency (2 to 3 Megahertz) radiotelephone system and make the privileges enjoyed by licensees of the older system available to even the most modest of users.

The Marine/Master-25w operates within the VHF-FM Marine Band (156 to 162 Megahertz). This system is not susceptible to the "skip" phenomenon which created channel crowding in the old MF system. Communications within the VHF-FM Band are "line-of-sight" . . . the higher the antenna: the greater the range (i.e. The taller the tower: the farther you can see.). This characteristic is effectively utilized within the VHF-FM marine service to maximize channel utilization. The tall antenna towers of the coastal stations allow them to communicate with ships far at sea, while the relative low antenna height of the ships serves to reduce the number of signals creating interference with the desired station.

An added feature of the VHF-FM Marine Band is the increased number of channels. The old MF system provided only a limited number of operating channels while the VHF-FM system provides over twice as many channels including 3 weather monitor channels.

VHF-FM is relatively free from static and other forms of noise interference. While static and ignition noise will cause some reduction in the receive efficiency of the VHF-FM system, it will not completely block the communications. Ignition noise from the ship's engine(s) . . . which causes a very slight reduction in receive efficiency, can be relatively inexpensively reduced by the installation of noise suppression equipment. Noise suppression equipment is not mandatory, although it may be desirable. Noise suppression information and kits can be obtained through marine and electronic suppliers.


Another point favoring VHF-FM is the increased antenna effectiveness which can be achieved. The old MF system, which needs long antennas for best performance, usually underwent a compromise in antenna effectiveness through the use of coils and various other loading and matching devices. Due to the frequency of VHF-FM, high efficiency antennas can be built of reasonable size. For example, there are two antenna models being offered with your Marine/Master-25w. These antennas can multiply the effective output of your radiotelephone without any modification whatsoever to the unit.

The Marine/Gain-50 technically is rated at 3db gain. In reality this antenna makes your Marine/Master-25w equivalent to 50 watts effective transmit power.

The Marine/Gain-100, which is rated at 6 db of antenna gain, makes your Marine/Master-25w equivalent to 100 watts effective transmit power.

INSTALLATION


INSTALLATION PLANNING



NOTE: The Marine/Master-25w does **not** require a metallic ground plate be installed on the ships hull surface.

Check your ship for a convenient location from which to operate your Marine/Master-25w. Consider the following points:

1. Locate the unit in a well protected site.
2. Try not to mount the unit within 1 foot of the ships compass.
3. Try to prevent extremely long power or antenna cable lengths.



UNIT INSTALLATION

1. Remove the Marine/Master-25w from the mounting yoke.
2. With screws or bolts securely fasten the yoke in the desired location. (Deck top, under dash, vertical wall, or bulkhead, or overhead if feasible) Unit performance is not affected by mounting position.
3. Replace unit in mounting yoke and tighten holding screws.
4. Connect the color-coded power leads to the power source. Take care to use RED for positive and BLACK for negative. Unit will only operate on a supply with negative ground. If it is necessary to extend power leads, use #14 gauge or heavier insulated copper wire. If polarity is reversed the unit will be inoperative. If this occurs check wiring polarity (RED to positive and BLACK to negative) and the protective fuse. A blown fuse should be replaced with a 5-amp, type 3AG fuse only.
5. Attach the microphone mounting clip to the desired mounting surface using two small screws or bolts.
6. The Marine/Master-25w installation is now complete except for installing and connecting the antenna.

ANTENNA INSTALLATION


The Marine/Gain-50 and the Marine/Gain-100 antennas are designed for operation with the Marine/Master-25w. Both of these antennas can be mounted on either a vertical or a horizontal surface. A few considerations to make when planning the antenna location are as follows:

- A. Antenna height is very important. The higher the antenna is installed, the greater the range.
- B. Do not mount the antenna too near a source of electrical noise (ship's engine, electrical motors, etc.) or in the radiation path of the ship's radar antenna.
- C. For maximum performance, try to prevent excessive antenna cable lengths.

To install the antenna proceed as follows:


1. Mount the antenna to the selected surface using bolts or screws.
2. Route the antenna cable to the Marine/Master-25w. If it is necessary to route the antenna cable through hull sides, decks, or bulkheads and still maintain a waterproof seal use a waterproof bulkhead fitting as illustrated on the next page. These fittings are available from your local marine supplier.
3. Secure the antenna cable. Be careful not to kink or pull the coaxial cable around corners or sharp edges. It is more desirable to have some "extra" cable than not enough.
4. Install coaxial antenna connector (See illustration on following page) and connect securely to the coaxial receptacle at the rear of the Marine/Master-25w.
5. Your Marine/Master-25w is now ready to operate.

CABLE CONNECTOR ASSEMBLY




1. Trim end of cable even. Remove outer jacket on cable to dimension shown.
2. Place connector ring and adapter sleeve on cable.
3. Fan out braid and fold back as shown. Tin inner conductor with solder. Press braid over adapter sleeve and trim to dimension shown.
4. Screw plug assembly onto adapter sleeve and solder braid to plug assembly through solder holes in side. Solder center conductor to plug assembly center pin. To finish assembly screw connector ring over plug assembly.

WATERPROOF BULKHEAD FITTING



This manual is for educational purposes only. The accuracy and completeness of the information provided herein is not guaranteed or warranted. Genave shall not be liable for any loss or damages. Use at your own risk. Unauthorized reproduction is prohibited. Copyright © 2007 Genave/NRC, Inc., all rights reserved.



OPERATING INSTRUCTIONS


1. Turn volume (#1) and squelch control (#2) knobs completely counterclockwise.
2. Move the OFF/1W/High switch (#3) to the 1W position.
3. Turn the volume control clockwise to adjust volume of the ceiver to the desired level.
4. Turn squelch control clockwise until background sounds just disappear. Don't adjust squelch when a signal is being received.
5. Select the desired channel by pushing the proper channel button.
6. To transmit: depress button on microphone, hold microphone 4 to 6 inches from mouth, and talk in a normal voice.
7. Release the microphone button to listen.

*Marine/Master-25w comes with 3 factory installed and tuned channels. They are 6, 16, and WX. (Mandatory channels: 16 for Distress, Safety and Calling; 6 for Intership Safety.) The weather monitor channel (WX) is for receive only.

MAINTENANCE

Keep the unit dry and check electrical connections regularly for satisfactory operation under most normal conditions.

This manual is for educational purposes only. The accuracy and completeness of the information provided herein is not guaranteed or warranted. Genave shall not be liable for any loss or damages. Use at your own risk. Unauthorized reproduction is prohibited. Copyright © 2007 Genave/NRC, Inc. All rights reserved.



Marine/Master-25w
Block Diagram

THEORY OF OPERATION

INTRODUCTION

The Genave Marine/Master-25w is a VHF FM transceiver intended for use in the marine radio services. It transmits and receives 16F3 emission in the frequency range from 156 to 162 MHz on any one of ten possible channels. The M/M-25w provides a nominal 25 watts of output power into a 50 ohm load.

RECEIVER

The receiver is basically a dual conversion superheterodyne type utilizing a single integrated circuit to perform the limiting and detection functions.

The received signal is applied from the antenna connector to the three pole low pass filter comprised of C270, L213, and C254. This filter also functions as a low pass filter for the transmit function. The signal from the low pass filter is applied to pin 15 of K201, the T/R relay. In the receive mode the signal is fed to the input filter of the receiver via pin 14 of the T/R relay.

The receiver input filter consists of L101, L102, and L103 and their associated tuning and coupling capacitors. The output of the input filter is capacitively coupled to the base of Q101, the first mixer.

The first local oscillator consists of Q107 and associated circuitry. The desired crystal in the 47.7250 to 50.0583 MHz range is selected by means of the frequency selection switch, SW202. The collector circuit of Q107 is tuned to the

third harmonic of the crystal frequency and the 143.175 to 150.75 MHz output is capacitively coupled to the base of Q101.

The 13.1 MHz difference signal produced in the first mixer is coupled to the first IF amplifier consisting of Q102 and associated circuitry. The output of the first IF amplifier is fed to Q103, a dual gate FET which together with its associated circuitry functions as the second mixer.

The second local oscillator operates at the crystal controlled frequency of 12.645 MHz. This 12.645 MHz signal produced is mixed with the 13.1 MHz signal from the first IF in the second mixer. The 455 KHz difference frequency produced by the second mixer is applied to the second IF amplifiers of Q104, Q105, Q106 and their associated circuitry.

The 455 KHz second IF signal is applied to pins 1 and 2 of IC101. IC101 performs the limiting and detection functions in the receiver. C130 sets the de-emphasis level in the detection circuitry. T111, R136, and C132 form the quadrature detector transformer circuit. Detected audio is fed from pin 8 of IC101 through C133 and R121 to the audio amplification circuits via pin 14.

Detected audio from pin 8 is also fed to the noise amplifier consisting of Q109 and associated circuitry. The amplified noise from Q109 is fed to the voltage doubling detector of CR101, CR102, and C137. The detected noise level is fed to the base of Q110. R127, the squelch control, controls the authority of the detected noise level on the base of Q110. As Q110 begins to turn on, the audio level at the output (pin 12) of IC101 is reduced.

R129, the volume control, sets the level of audio fed to IC102, the audio amplifier. R130 and C140, and R131 and C141 perform the frequency response shaping of the audio amplifier while C143, C144, and C147 provide feedback to various stages within IC102. Output audio from IC102 is applied from pin 12 through C146 to the speaker.

TRANSMITTER

The modulator audio amplifier in the M/M-25w is built around a single integrated circuit, IC201. This IC is a dual operational amplifier and is shown in the schematic diagram as IC201A and IC201B. The audio output of the ceramic microphone is amplified by IC201A. A 6 db/octave rising characteristic is given to the audio frequencies by loading the 1500 pfd microphone capacitance with the bias resistors, R231 and R232. IC201 also provides the clipping function required for limiting the modulation by saturating symmetrically against the supply voltage and ground. The regulated supply voltage for the modulator is obtained by applying 13.75 VDC primary power through R201 and across a 6.8 volt zener diode, CR210.

The output from IC201A is applied to IC201B which acts as an active, 2-pole, Chebyshev low pass filter with a cutoff frequency of 3 KHz. R238 and C266 add a third pole to the filter which gives the required — 18 db/octave 3 KHz.

R239 controls the audio level applied to the modulator varactor diode, CR202. R207 and C215 convert the audio signal applied to the modulation diode to the form required to produce frequency modulation instead of phase modulation.

DC bias for the modulation diode is provided by IC201B through R238, R239, and R207. The audio return from R239 is provided by C267.

Q201 is the oscillator transistor and accordingly generates the required RF signal. Power for the oscillator is derived from the same power source used by the modulator (R201 and CR210). The oscillator is a basic Colpitts or Clapp crystal circuit. Variable capacitors are used in series with each crystal to allow exact setting of the generated frequency. Output from the oscillator is from 13.00416 to 13.11875 MHz. The oscillator output is multiplied by 12 in the multiplier stages resulting in a final output frequency from 156.025 to 157.425 MHz.

Unlike the rest of the transmitter, the oscillator is not turned on and off with its supply voltage. The bias resistor, R203, returns to the +13.75 VDC receiver power line. Therefore, when in the receive mode, Q201 is saturated by the current flowing through R203 and accordingly oscillation ceases. This action insures that power will be continuously applied to the modulator thereby eliminating switching transients in the output of the modulator.

Frequency modulation of the carrier signal is accomplished by CR202. A signal from Q201, the oscillator transistor, is applied to CR202 by a tuned transformer, T201. As an audio signal is applied to the varactor diode, CR202, from the modulator audio amplifier: the capacitance of the diode changes thus varying the resonant frequency of the tuned transformer, T201. This results in phase modulation of the carrier signal. The audio signal is de-emphasized before application to CR202, however, resulting in frequency modulation of the carrier rather than phase modulation.

The output of the modulator is first applied to Q202, an RF tripler. In this stage the input frequency of 13.1 MHz is multiplied to 39.3 MHz. Other harmonics and subharmonics are filtered out by a double-tuned transformer, T202. The output of T202 is fed to Q203, a Class C doubler, which increases the signal frequency to 78.6 MHz. The undesired signals generated in this stage are removed by the tuned transformer, T203.

The output of T203 is applied to the base of Q204, the last multiplier stage. Q204 doubles the signal frequency to 157.2 MHz. The output of Q204 is matched to the input of Q205 by a resonant "L" section consisting of L201 and C230. This circuit also provides some degree of subharmonic suppression.

The power amplifier in the M/M-25w transmitter consists of Q205, Q206, Q207 and associated circuitry. The complement of devices increases the output from Q204, nominally 50 milliwatts, to the rated output of the transmitter, 25 watts. Frequency selective matching networks are used between each of the stages to effectively couple power between devices and to reject the unwanted spurious responses from the desired signal.

SW201A switches R224 into a series connection between the collector supply and Q206 when the switch is in the "1W" position. This reduces the output power of the transmitter to 1 watt for short distance, low power drain operation.

A relatively complex filter is used in the M/M-25w to remove subharmonic spurious outputs and harmonic radiations from the RF signal prior to transmission. C246, C247, L207, and C248 comprise a resonant matching network which matches the output of Q207 to the 50 ohm antenna impedance. The remainder of the components up to the output connector form an elliptic function, filter which reduces the level of all spurious outputs to less than -13 dbm.

PRIMARY POWER

Power to operate the unit is supplied from the 13.75 VDC external power source via the input connector, F201, and SW201B. The 13.75 VDC line supplies power to operate the relay, K201; the panel backlighting lamps, DS101 and DS102; the transmitter oscillator, via R201; and the remaining transmitter and receiver circuitry, via Pins 11, 12, and 13 of K201.

The transceiver is protected against a reversed polarity input voltage by means of CR203 and CR205. CR204 prevents the feedback of induced voltage spikes generated by K201, on the 13.75 VDC line. C268 acts as a filter on the 13.75 VDC line. C268 acts as a filter on the 13.75 VDC line.

ALIGNMENT PROCEDURE

GENERAL

The M/M-25w comes prealigned from the factory and realignment should never be necessary during the normal life of the unit unless components within the M/M-25w have been replaced due to damage. NEVER attempt to realign the circuitry of the M/M-25w unless the test equipment specified for each section is available.

RECEIVER ALIGNMENT

PREPARATION

To properly align the receiver of the M/M-25w the following test equipment or its equivalent is required:

- a. Oscilloscope, DC—8MHz, DC coupled, Calibrated vertical attenuator, (Heath kit 10-14, or equivalent).
- b. RF Signal Generator, 13.1 MHz, 156 MHz, and 163.5 MHz.
- c. Sweep Signal Generator, Must be capable of sweeping the frequency range 156 to 158 MHz.
- d. FM Signal Generator, Must cover the frequency range 156 to 163.5 MHz with a deviation of at least 5 KHz at 1000 Hz.
- e. Frequency Counter, DC—150 MHz.
- f. AC VTVM, any accurate instrument.
- g. DC Power Supply, low ripple.

To facilitate test-equipment connections to the bottom of the receiver board at the following points:

- Secondary pins of T110 (455 KHz output transformer)
- Pin 3 of T102 (13.1 MHz output coil)
- Tap of L103 (RF filter output coil)
- Emitter of Q101 (1st mixer transistor)

Depress the ch. 6 frequency selector button and turn the volume and squelch controls fully counterclockwise.

Connect the transceiver to a 13.75 VDC, filtered power supply.

455 KHz IF ALIGNMENT

1. Connect the scope vertical input to the secondary of T110 with a length of 6 ft co-ax cable. Set the scope vertical attenuation for maximum sensitivity.
2. Connect the RF output of the RF signal generator to the frequency counter and set the frequency to exactly 13.1 MHz, unmodulated.
3. Disconnect the frequency counter, and connect the RF output of the Signal Generator between Pin 3 of T102 and receiver ground.
4. Turn the transceiver power switch on, and adjust the Signal Generator RF attenuator and scope controls to give a usable pattern of the 455 KHz IF signal.

NOTE: Small changes in the amplitude of the IF signal are more easily seen if the attenuator on the signal generator is kept set so that the IF signal covers about 3/4 of the scope screen vertically, and the scope internal sweep is set slow enough to display a large number of IF cycles.

5. Tune the cores of 455 KHz IF transformers T110, T109, T108, T107, T106, T105, T104, and T103 (in that order) for maximum amplitude on the scope. Reduce signal generator attenuator as necessary to keep a usable presentation on the scope.
6. Turn the transceiver power switch OFF, and disconnect the RF cable of the signal generator from Pin 3 of T102. Check that the signal generator is still set exactly to 13.100 MHz.

13.1 MHz IF ALIGNMENT

1. Connect the RF cable of the signal generator between the tap of L103 and ground. Leave oscilloscope connected as above.
2. Turn the transceiver power switch on, and reduce the setting of the signal generator RF attenuator to keep a useable presentation on the scope screen.
3. Adjust the bottom core of T102 for maximum amplitude. Adjust bottom and top cores of T101 for maximum amplitude.
4. Adjust all four cores in this manner, until no further increase in amplitude can be obtained.

- Turn the transmitter power switch OFF, and disconnect the oscilloscope and the signal generator from the transmitter.

RF-INPUT FILTER ALIGNMENT

- With the transmitter still off, connect the RF output cable of the sweep generator to the transmitter ANT connector. Connect the vertical input of the oscilloscope between the emitter of Q101 and transmitter ground.
- Set the sweep generator to sweep from 156 MHz to 163.5 MHz. Use the RF signal generator as a marker generator to produce 156 and 163.5 MHz markers.
- Turn the transmitter power switch on.
- Set the scope vertical attenuator to the most sensitive position, and set the RF output of the sweep generator low enough to prevent over driving the RF input filter.
- Adjust C101, C103, and C105 to give a 4 MHz bandpass similar to that shown in figure 1.
- Turn the transmitter power switch off, and disconnect the test equipment from the transmitter.


OSCILLATOR COIL ADJUSTMENT

CAUTION: Never depress the microphone push-to-talk button while a signal generator is connected to the ANTENNA connector, as the transmitter power would damage the RF attenuator.

- Using the frequency counter, set the FM signal generator exactly to 156.3 MHz. Disconnect the frequency counter from the FM signal generator RF cable and connect the RF cable to the transmitter ANTENNA connector. The FM signal generator RF attenuator should be set to the minimum position, and the modulation should be off.
- Set the AC VTVM, or other DB meter, to a convenient range, such as -10 db, and connect the meter leads across the speaker voice coil.
- The transmitter frequency selector button for ch. 6 should still be depressed, the squelch and volume controls turned fully counterclockwise.
- Turn the transmitter power switch on.
- Adjust the volume control clockwise until the receiver background noise indicates -10 db on the AC VTVM. Increase the setting of the FM signal generator RF attenuator until the receiver background noise drops to approximately -27 db (17 db quieting).
- Adjust the RF filter capacitor, C105, for maximum quieting (minimum indication on the AC VTVM).
- Tune the core of the oscillator coil, L104, for maximum quieting. If necessary, reduce the output of the signal generator, to keep a readable indication on the DB meter.
- Turn the transmitter power switch off, but leave the FM signal generator and DB meter connected to the transmitter.

DETECTOR TRANSFORMER ADJUSTMENT

- Connect the oscilloscope vertical input cable across the speaker voice coil, paralleling the AC VTVM leads.
- Check to insure that the FM signal generator is still set to 156.3 MHz. Set the signal generator modulation for 5 KHz deviation at 1 KHz. The signal generator RF attenuator should be set in the vicinity of 2 microvolts.
- Turn the transmitter power switch on, and adjust the scope controls to give a readable display of the 1 KHz modulation.
- Adjust the core in the discriminator transformer, T111, for best linearity of the 1 KHz signal. The AC VTVM and the scope will show maximum amplitude of the 1 KHz modulation at this point.
- The receiver is correctly aligned now, and the sensitivity for 20 db quieting may be checked. Leave the test equipment connected to the transmitter.



Swept Input Filter
Figure 1

RF INPUT FOR 20 DB QUIETING

- Turn the FM signal generator modulation off, and ascertain that the generator is set exactly to 156.3 MHz. Set the FM signal generator RF attenuator for minimum output.
- Check that the transmitter is set on channel 6. Adjust the transmitter volume control so that the receiver background noise indicates -10 db on the AC VTVM.
- Slowly increase the setting of the FM signal generator RF attenuator, until the AC VTVM indicates -30 db. Note the RF level shown on the FM signal generator attenuator. This is the RF input required to produce 20 db receiver quieting. Normally, an input of -109 dbm (0.8 uvolt) to -112 dbm (0.55 uvolt) will quiet the receiver 20 db.
- Check the receiver quieting with the transmitter and signal generator on each additional frequency installed in the unit. On each frequency the receiver should quiet 20 db with an input of -109 dbm (0.8 uvolt) to -112 dbm (0.55 uvolt).

SQUELCH OPERATION

- Set the signal generator on 156.3 MHz, and set the modulation for 5 MHz deviation at 1 KHz. Set the RF attenuator for minimum RF output.
- Set the transmitter on channel 6, and turn the squelch control fully clockwise. The receiver audio control should be set for maximum volume. The receiver is now fully squelched, and should be completely silent.
- Reduce the DC input voltage to approximately 11 volts, and note that the receiver is still fully squelched. Return DC input to 13.75 VDC, and set volume control at midrange.
- Increase the setting of the signal generator RF attenuator until the squelch just fully opens. The RF attenuator should show -111 dbm (0.6 uvolt) or better.
- Repeat the above steps for each additional frequency installed in the unit. On each frequency, the squelch should open at approximately -110 dbm or better.

AUDIO OUTPUT POWER

- Set the FM signal generator on 156.3 MHz, and set the modulation for 5 KHz deviation at 1 KHz. Set the RF attenuator in the vicinity of 5 microvolts.
- Set the transmitter on channel 6 and turn the volume control fully clockwise. The AC VTVM should indicate not less than 2.83 volts (1 watt).
- Set the signal generator for 5 KHz deviation at 400 Hz, and note that the AC VTVM indicates at least 2.83 volts with the transmitter volume control fully clockwise.
- Set the signal generator for 5 KHz deviation at 3 KHz. Again the AC VTVM should indicate at least 2.83 volts at maximum setting of the transmitter volume control.
- Turn off the transmitter power switch, and disconnect the AC VTVM and oscilloscope from the transmitter.

FREQUENCY MEASUREMENT

To insure that the receiver will operate on the correct frequency, each time frequency oscillator crystal frequency should be measured. The frequency should be within plus or minus .003% of the frequency found in the table on page 24, which corresponds to the frequency stamped on the crystal case divided by 3.

Tolerance = $\pm (.003\%) \times$ Stamped Table Frequency

Example: for Ch. 6 (156.3 MHz)

Tolerance = $\pm (.003) \times 156.3$ MHz

= 1.563 KHz

Connect the frequency counter to the transmitter with a short length of coax cable. The braid should be connected to the transmitter chassis, and the inner-conductor should be connected to the tap (pin 3) of the oscillator coil, L104.

- Turn the transmitter power switch on.
- Depress the channel 6 frequency selector button, and read the crystal frequency, which should fall within the range listed above.
- Repeat these steps for each receive frequency installed in the unit.
- Turn off power switch, and disconnect frequency counter.

TRANSMITTER ALIGNMENT

PREPARATION

To properly align the transmitter of the M/M-25w the following test equipment or its equivalent is required:

- Power Meter, 35 watts @ 163 MHz, or relative output indicating device. (See figure 4.) with 50 ohm dummy load.
- Frequency Counter, DC—165 MHz, or other accurate frequency measuring device.
- Deviation Meter, to read ± 7.5 KHz.
- Power Supply, 13.75 VDC at 8 amp minimum, filtered.
- VTVM. Any accurate instrument.
- Audio Generator, 1700 Hz.

To prepare the unit for alignment perform the following steps:

- Attach a 50 ohm dummy load to the RF output connector through a power meter or relative output indicating device (figure 4).
- Set the OFF/1W/HIGH switch to the HIGH position.
- Preset the deviation potentiometer to its lowest setting (potentiometer rotated toward the receiver 3-pole input filter capacitor trimmers).
- Connect the unit to a 13.75 VDC power source.

FREQUENCY AND POWER ALIGNMENT

- Depress the channel 6 frequency selector button.

NOTE: The signal peak voltage measurements in the following steps of this section were made with a VTVM and DC probe. Key the transmitter *only* when adjustments are being made.

- Connect the DC probe to the emitter of Q202, key the transmitter and adjust the single slug of T201 for a peak at 13.025 MHz. Adjust the VTVM attenuator for an on-scale reading.

NOTE: T201's slug will peak in two places... the peak with the slug closest to the printed circuit board is correct. The peak should reach about 1.4 volts.

- Move the DC probe to the emitter of Q203. Key the transmitter and adjust the 2 slugs of T202 for a peak, centered on 39.075 MHz. Each slug should adjust between the winding and the outside end of the coil form. The signal should peak at about 0.38 volts.
- Adjust T203 by connecting the DC probe to the emitter of Q204, keying the transmitter, and adjusting the 2 slugs of T203 for a peak centered on 78.150 MHz. Each slug should adjust between its winding and the outside end of the coil form. The signal should peak at about 1.2 volts.
- If the relative output indicating device of figure 4 is used, connect the VTVM DC probe to the relative output terminal. Otherwise, observe the wattmeter or other relative output indicator.
- Preset C235 by tightening the adjustment screw down firmly and backing it off $\frac{1}{2}$ turn.
- Key the transmitter and adjust C230, C234, C235, C239, C243, C247, and C248 for maximum relative output indication on 156.300 MHz. This step may be repeated if necessary.
- With the Channel 6 pushbutton still depressed and the OFF/LO/HIGH switch in the HIGH position, key the transmitter and adjust C203, the channel 6 crystal netting trimmer, for a frequency reading of 156.300 MHz on the frequency measuring device.
- Repeat the above procedure for each transmit crystal installed in the M/M-25w, adjusting its respective netting trimmer for the frequency stamped on the top of the crystal case.

POWER MEASUREMENT PROCEDURE

- Depress the Channel 6 pushbutton.
- Key the transmitter and note the transmitter power reading on Channel 6. It should be no less than 25 watts.
- Repeat the above step for each transmit frequency installed.
- Set the OFF/1W/HIGH switch to the 1W position.
- Key the transmitter and note the transmitter power reading on Channel 6. The power level on the 1W position is factory adjusted to approximately 1 watt, the maximum FCC limit, by changing the value of R224.
- Repeat the above step for each transmit frequency installed.

CARRIER DEVIATION ADJUSTMENT

- Depress the Channel 6 pushbutton.

2. Set the OFF/1W/HIGH switch to the 1W position.

3. Connect the deviation meter to the frequency measuring output of the relative output indicating device.

- Feed an audio signal of 1700 Hz into the transceiver microphone.

4. Key the transmitter, observe the frequency deviation meter, and increase the microphone audio input until no further increase in deviation is indicated. The modulator stage is now saturated.

5. With the frequency deviation meter set to either + or - deviation, key the transmitter and adjust the slug of T201 for a peak reading. The deviation potentiometer, R239, can be adjusted for an on-scale reading of the deviation meter.

6. Set the deviation potentiometer, R239 for a deviation reading of 5 KHz. Switch the deviation meter to the + and - positions and check the amount of deviation in each position.

7. If a difference exists between + and - deviation levels adjust T201 by rocking the slug slightly until the two levels are brought into balance. The difference in deviation levels should not exceed 0.4 KHz.

FREQUENCY CHANGES

To add additional channels to the Marine/Master-25w it is only necessary to obtain the necessary crystal kit from Genave, install the new transmit and receive crystal in their appropriate socket, replace the corresponding pushbutton with the new pushbutton supplied, and perform steps 8 and 9 of the Transmitter Frequency and Power Alignment procedure outlined on the preceding page.

The charts on pages 24 and 25 of this manual will aid in selection of the desired frequencies to be installed. When ordering crystals from Genave be sure to specify the channel desired, the type of crystal desired (receive, transmit or both), and the Model Designation: Marine/Master-25w.


RECEIVER SENSITIVITY & GAIN MEASUREMENTS

Frequency	Input Point	Measurement Point	Measured Value
156.3 MHz	Ant. Conn.	Across Speaker	-109 dbm or better for 20 db quieting
13.1 MHz	Tap L103	Sec. T110	500 uv or less for 0.3 V P-P (Scope)
13.1 MHz	Pin 3 T102	Pri. T104	45 mv for 0.3 V P-P (Scope)
13.1 MHz	Pin 3 T102	Source Q104	70 mv for 0.3 V P-P (Scope)
13.1 MHz	Pin 3 T102	Drain Q104	11 mv for 0.3 V P-P (Scope)
13.1 MHz	Pin 3 T102	Pri. T106	13 mv for 0.3 V P-P (Scope)
13.1 MHz	Pin 3 T102	Source Q105	23 mv for 0.3 V P-P (Scope)
13.1 MHz	Pin 3 T102	Drain Q105	3.4 mv for 0.3 V P-P (Scope)
13.1 MHz	Pin 3 T102	Pri. T108	5.5 mv for 0.3 V P-P (Scope)
13.1 MHz	Pin 3 T102	Source Q106	10 mv for 0.3 V P-P (Scope)
13.1 MHz	Pin 3 T102	Drain Q106	1.5 mv for 0.3 V P-P (Scope)
13.1 MHz	Pin 3 T102	Pri. T110	1.5 mv for 0.3 V P-P (Scope)
13.1 MHz	Ant. Conn.	Across Speaker	3 mv for 0.3 V P-P (Scope)
156.3 MHz			2 uv or better for 1 watt output, 400 to 3000 Hz.

DC VOLTAGE MEASUREMENTS

All voltages shown in this table were measured with a VTVM from chassis ground. The DC input to the radio should be set to 13.75 VDC. The squelch control should be in the full off position and the volume control in the minimum position. No signal should be applied. The receiver A+ line should measure 13.0 VDC. A variation of $\pm 20\%$ of the measured voltages from those listed may be considered normal.

Ref. No.	E	B	C	or	D	S	G	G ²
Q101	1.8	2.4	12.4					
Q102					12.4	0	0	
Q103					11.0	0	0	5.8
Q104					11.0	0	0	
Q105					11.6	0	0	
Q106					11.6	0	0	
Q107	6.8	6.2	0					
Q109	0	0.6	2.8					
Q110	0	0.47	5.8					
Q111	0	0.42	5.8					
Q201 (Recv)	6.5	7.2	6.8					
Q201 (Xmit)	2.5	3.2	6.8					
P _{in} 1	2	3	4	5	6	7	8	9
IC101	2.0	2.0	0	0	11.5	—	5.6	4.8
IC102	12.8	—	7.7	0.8	0.6	—	0	0
							5.4	4.1
							5.8	1.6
							—	12.9



Relative Output Indicator
Figure 4

RECEIVER PREAMPLIFIER

DESCRIPTION

The receiver preamplifier consists of a single N-channel dual-gate MOS FET RF amplifier with LC tuned input and output. The input and output are LC coupled to 50 ohm coaxial cables which connect to the receiver circuit board. The broadband preamplifier circuitry provides a nominal 6 to 9 db of additional gain over the receiver tuning range. All power necessary for operation of the preamplifier is provided by the transceiver.

The entire preamplifier is constructed on a 1 inch by 1.4 inch epoxy-fiber glass circuit board. The preamplifier is enclosed on four sides by a tin-plated steel enclosure which is predrilled on one side for convenient mounting.

The information herein contained can be used to install the receiver preamplifier in Genave transceivers which are not so equipped. If your transceiver has the receiver preamplifier presently installed this information is intended to assist you should maintenance ever be required.

INSTALLATION PROCEDURES

1. Remove the transceiver from its protective case.
2. Using a knife or similar instrument, carefully cut the receiver input track and relay ground connection in the appropriate locations as shown in Figure A.
3. Remove the speaker from its mounting tabs.
4. Drill the appropriate holes in the circuit board as shown in Figure A. The two holes for the preamplifier input and output cables grounds should be drilled with a 1/16 inch diameter drill. The remaining three holes should be drilled with a #60 (.040 inch diameter) drill.
5. Prepare the preamplifier input and output cables, insert them into their appropriate circuit board holes and solder them in place (See Figure B).
6. Insert the red preamplifier A+ lead into its appropriate hole in the circuit board and solder.
7. Place the predrilled side of the preamplifier case over the speaker mounting tab located on the siderail closest to the power lead grommet. Secure the preamplifier in place between the speaker and the speaker mounting tab using the speaker mounting screw (See Figure D). Replace the other speaker mounting screw.
8. Reinstall the transceiver in its protective case.




Figure A

CABLE CONNECTIONS




Figure B




Figure C

ALIGNMENT PROCEDURES

1. Set receiver to a frequency at approximate center of receiving range.
2. Apply a signal to receiver input at a low level such that noise heard on the received audio.
3. By alternately tuning C302 and C304 and by reducing the applied signal level tune the preamplifier for minimum noise on the received audio.

NOTE: The above alignment may be performed using either a signal generator or "on-the-air" signals.

SCHEMATIC DIAGRAM




Figure D






Figure E

PREAMPLIFIER PARTS LIST

Ref. No.	GENAVE Part No.	Description
CAPACITORS		
C301	1520004	NPO Disc, 4.7 pfd, 10%
C302	1570120	Trimmer, 1-6 pfd
C303	1520033	Z5F Disc, 220 pfd, 10%
C304	1520120	Trimmer, 1-6 pfd
C305	1520033	Z5F Disc, 220 pfd, 10%
COILS		
L301	1800073	R.F. Input
L302	1800074	R.F. Output
RESISTORS		
R301	4710008	100 ohm, 10%, 1/4W
R302	4710030	15K, 10%, 1/4W
R303	4710025	4.7K, 10%, 1/4W
SEMICONDUCTORS		
Q301	4800054	Dual Gate, N-Channel, MOS-FET, MPF-120 or 3N201






Marine/Master-25W
Schematic
Figure 5

This manual is for educational purposes only. The accuracy and completeness of the information provided herein is not guaranteed or warranted. Genave shall not be liable for any loss or damages. Use at your own risk. Unauthorized reproduction is prohibited. Copyright © 2007 Genave/NRC, Inc., all rights reserved.

Marine/Master-25w
Parts/Track Map
Figure 6



This manual is for educational purposes only. The accuracy and completeness of the information provided herein is not guaranteed or warranted. Genave shall not be liable for any loss or damages. Use at your own risk. Unauthorized reproduction is prohibited. Copyright © 2007 Genave/NRC, Inc. All rights reserved.

MARINE/MASTER-25 PARTS LIST

Ref. No.	Genave Part No.	Description
CAPACITORS		
C101	1570120	Trimmer, 1.6 pf
C102	1510004	NPO Gimmick, 27 pf
C103	1570120	Trimmer, 1.6 pf
C104	1510004	NPO Gimmick, 27 pf
C105	1570120	Trimmer, 1.6 pf
C106	1520005	NPO Disc, 6.8 pf, 10%
C107	1510011	NPO Gimmick, 1.0 pf, 10%
C108	1520051	Y5U, Disc, .01 mfd, 25V, 10%
C109		Unassigned
C110	1520176	N330, Disc, 82 pf, 10%
C111	1520048	Z5P, Disc, .001 mfd, 10%
C112	1520176	N330, Disc, 82 pf, 10%
C113	1520176	N330, Disc, 82 pf, 10%
C114	1520051	Y5U, Disc, .01 mfd, 25V, 10%
C115	1520176	N330, Disc, 82 pf, 10%
C116		Unassigned
C117	1520027	N750, Disc, 150 pf, 10%
C118	1520027	N750, Disc, 150 pf, 10%
C119	1520175	NPO, Disc, 7.5 pf, 5%
C120	1520175	NPO, Disc, 7.5 pf, 5%
C121	1520054	M25, Disc, .05 mfd, 25V, + 80 - 20%
C122	1520175	NPO, Disc, 7.5 pf, 5%
C123	1520054	M25, Disc, .05 mfd, 25V, + 80 - 20%
C124	1520054	M25, Disc, .05 mfd, 25V, + 80 - 20%
C125	1520054	M25, Disc, .05 mfd, 25V, + 80 - 20%
C126	1520019	M25, Disc, .05 mfd, 25V, + 80 - 20%
C127	1520019	M25, Disc, .05 mfd, 25V, + 80 - 20%
C128	1520019	M25, Disc, .05 mfd, 25V, + 80 - 20%
C129	1520048	Z5P, Disc, .001 mfd, 10%
C130	1540014	Aluminum Electrolytic, 10 mfd, 16V
C131	1520044	Y5E, Disc, 820 pf, 10%
C132	1520022	N220, Disc, 100 pf, 10%
C133	1520022	N220, Disc, 100 pf, 10%
C134	1520051	Y5U, Disc, .01 mfd, 52V, 10%
C135	1520037	Y5E, Disc, 330 pf, 10%
C136	1520051	Y5U, Disc, .01 mfd, 25V, 10%
C137	1540014	Aluminum Electrolytic, 10 mfd, 16V
C138	1500024	Mylar, .022 mfd, 10%, 100V
C139	1520055	Z5P, Disc, .001 mfd, 10%
C140	1520048	Z5P, Disc, .001 mfd, 10%
C141	1520055	Z5P, Disc, .001 mfd, 10%
C142	1520055	Z5P, Disc, .001 mfd, 10%
C143	1550005	Tant, 10 mfd, 25V, 10%
C144	1500004	Tant, 47 mfd, 10%, 15V
C145	1540038	Polyethylene, .0015 mfd, 10%, 250V
C146	1540212	Aluminum Electrolytic, 1000 mfd, 30V
C147	1520176	Aluminum Electrolytic, 200 mfd, 12V
C148	1520007	N330, Disc, 82 pf, 10%
C149		NPO, Disc, 10 pf, 10%
C150		Unassigned
C202	1520054	Unassigned
C203	1560403	M25, Disc, .05 mfd, + 80 - 20%, 25V
C204	1560403	Trimmer, 40 pf
C205	1560403	Trimmer, 40 pf
C206	1560403	Trimmer, 40 pf
C207	1560403	Trimmer, 40 pf
C208	1560403	Trimmer, 40 pf
C209	1560403	Trimmer, 40 pf
C210	1560403	Trimmer, 40 pf
C211	1560403	Trimmer, 40 pf
C212	1560403	Trimmer, 40 pf
C213	1560403	Trimmer, 40 pf
C214	1520027	N750, Disc, 150 pf, 10%
C215	1520027	N750, Disc, 150 pf, 10%
C216	1520048	Z5P, Disc, .001 mfd, 10%
C217	1520176	N330, Disc, 82 pf, 10%
C218	1520176	N330, Disc, 82 pf, 10%
C219	1520053	N330, Disc, 82 pf, 10%
C220	1520051	N750, Disc, .01 mfd, 10%, 25V
C221	1520027	N750, Disc, 150 pf, 10%
C222	1520027	N750, Disc, 150 pf, 10%
C223	1520010	NPO, Disc, 18 pf, 10%
C224	1520048	Z5P, Disc, .001 mfd, 10%
C225	1520027	N750, Disc, 150 pf, 10%
C226	1520012	NPO, Disc, 27 pf, 10%
C227	1520015	N1500, Disc, 47 pf, 10%
C228	1520048	Z5P, Disc, .001 mfd, 10%



Ref. No.	Genave Part No.	Description
C229	1520054	M25, Disc, .05 mtd, +80 -20%, 25V
C230	1560403	Trimmer, 40 pf
C231	1520048	Z5P, Disc, .001 mtd, 10%
C232	1520048	Unassigned
C233	1520048	Z5P, Disc, .001 mtd, 10%
C234	1560403	Trimmer, 40 pf
C235	1560403	Trimmer, 40 pf
C236	1520013	NPO, Disc, 35pf, 10%
C237	1520042	Y5E, Disc, 470 pf, 10%
C238	1540002	Aluminum Electrolytic, 1 mtd, 40V
C239	1560406	Trimmer 115 pf
C240	1520054	M25, Disc, .05 mtd, +80 -20%, 25V
C241	1520048	Z5P, Disc, .001 mtd, 10%
C242	1520022	N220, Disc, 100 pf, 10%
C243	1560406	Trimmer, 115 pf
C244	1520054	M25, Disc, 0.5 mtd, +80 -20%, 25V
C245	1520004	Z5P, Disc, .001 mtd, 10%
C246	1520014	NPO, Disc, 39 pf, 10%
C247	1560406	Trimmer, 115 pf
C248	1560406	Trimmer, 115 pf
C249	1520011	NPO, Disc, 22 pf, 10%
C250	1520011	NPO, Disc, 22 pf, 10%
C251	1520011	NPO, Disc, 22 pf, 10%
C252	1520011	NPO, Disc, 22 pf, 10%
C253	1520011	NPO, Disc, 22 pf, 10%
C254	1520011	NPO, Disc, 22 pf, 10%
C255	1520022	N220, Disc, 100 pf, 10%
C256	1520022	N220, Disc, 100 pf, 10%
C257	1520028	Y5E, Disc, 150 pf, 10%
C258	1520028	Y5E, Disc, 150 pf, 10%
C259	1520028	Y5E, Disc, 150 pf, 10%
C260	1520028	Y5E, Disc, 150 pf, 10%
C261	1540014	Aluminum Electrolytic, 10 mtd, 16V
C262	1520013	NPO, Disc, .02 mtd, 10%, 25V
C263	1520028	Y5E, Disc, 150 pf, 10%
C264	1520028	Y5E, Disc, 150 pf, 10%
C265	1520028	Y5E, Disc, 150 pf, 10%
C266	1520028	Y5E, Disc, 150 pf, 10%
C267	1520028	Y5E, Disc, 150 pf, 10%
C268	1520028	Y5E, Disc, 150 pf, 10%
C269	1520028	Y5E, Disc, 150 pf, 10%
C270	1520028	Y5E, Disc, 150 pf, 10%
C271	1520034	Unassigned
DIODE		
CR101	4810021	IN34A, Germanium
CR102	4812109	IN34A, Germanium
CR202	4812109	Varicap, MV2109 or SKV1638
CR203	4810013	Gen. Purpose, 100V @ 1 amp
CR204	4810013	Gen. Purpose, 100V @ 1 amp
CR205	4810013	Gen. Purpose, 100V @ 1 amp
LAMPS		
DS101	3900025	Clear—14.4V #53
DS102	3900025	Clear—14.4V #53
DS201	3900025	Clear—14.4V #53
COILS		
L101	1800109	Coil Input
L102	1800107	Coil Center Pole Input Filter
L103	1800108	Coil Output
L104	1800200	Coil, Osc.
L201	1800201	Coil, Transmitter
L202	1800201	Coil, Transmitter
L203	1800201	Coil, Transmitter
L204	1800202	Coil, Transmitter
L205	1800201	Coil, Transmitter
L206	1800204	Coil, Transmitter
L207	1800201	Coil, Transmitter
L208	1800204	Coil, Transmitter
L209	1800201	Coil, Transmitter
COILS		
L210	1800203	Etched on Circuit Board
L211	1800203	Coil, Transmitter
L212	1800205	Etched on Circuit Board
L213	1800205	Coil, Transmitter
TRANSISTORS		
Q101	4800024	Silicon, NPN, Blue, MPS 3563
Q102	4805484	JFET, N, Channel, 2N5484
Q103	4800122	MOSFET, N, Channel, Dual Gate, MPF 122
Q104	4805458	JFET, N, Channel, 2N5458
Q105	4805458	JFET, N, Channel, 2N5458
Q106	4800443	Silicon, PNP, 2N5227
Q107	4800443	Unassigned
Q108	4800028	Silicon, NPN, Red, MPS 6513S
Q109	4800028	Silicon, NPN, Red, MPS 6513S
Q110	4800033	Silicon, NPN, Red, MPS 6513S
Q111	4800033	Silicon, NPN, Red, MPS 6513S
Q201	4800033	Silicon, NPN, MPS 5172
Q202	4800033	Silicon, NPN, MPS 5172
Q203	4800026	Silicon, NPN, White, MPS 5693S
Q204	4804427	Silicon, NPN, 2N4427
Q205	4804427	Silicon, NPN, 2N4427
Q206	4806080	Silicon, NPN, 2N6080
Q207	4806080	Silicon, NPN, 2N6080
RESISTORS		
R101	4700009	10 ohm, ±10%, 1/2 W
R102	4700037	10K ohm, ±10%, 1/2 W
R103	4700029	2.2K ohm, ±10%, 1/2 W
R104	4700025	1K ohm, ±10%, 1/2 W
R105	4700013	100 ohm, ±10%, 1/2 W
R106	4700013	100 ohm, ±10%, 1/2 W
R107	4700049	Unassigned
R108	4700049	Unassigned
R109	4700049	100K ohm, ±10%, 1/2 W
R110	4700049	100K ohm, ±10%, 1/2 W
R111	4700049	100K ohm, ±10%, 1/2 W
R112	4700049	100K ohm, ±10%, 1/2 W
R113	4700013	100 ohm, ±10%, 1/2 W
R114	4700049	100K ohm, ±10%, 1/2 W
R115	4700049	100K ohm, ±10%, 1/2 W
R116	4700033	100K ohm, ±10%, 1/2 W
R117	4700033	100K ohm, ±10%, 1/2 W
R118	4700027	2.2K ohm, ±10%, 1/2 W
R119	4700027	2.2K ohm, ±10%, 1/2 W
R120	4700009	10K ohm, ±10%, 1/2 W
R121	4700033	220K ohm, ±10%, 1/2 W
R122	4700043	33K ohm, ±10%, 1/2 W
R123	4700043	33K ohm, ±10%, 1/2 W
R124	4700053	220K ohm, ±10%, 1/2 W
R125	4700037	10K ohm, ±10%, 1/2 W
R126	4700031	3.3K ohm, ±10%, 1/2 W
R127	4760024	Variable, Linear Taper, 25K, ±20% (SQ)
R128	4760025	Variable, Linear Taper, 25K, ±20% (SQ)
R129	4700037	Unassigned
R130	4700037	Variable, Audio Taper, 25K, ±20% (Vol)
R131	4700015	10K ohm, ±10%, 1/2 W
R132	4700015	10K ohm, ±10%, 1/2 W
R133	4700033	150 ohm, ±10%, 1/2 W
R134	4700033	4.7K ohm, ±10%, 1/2 W
R135	4700045	470K ohm, ±10%, 1/2 W
R136	4700037	10K ohm, ±10%, 1/2 W
R137	4700037	Unassigned
R201	4700015	150 ohm, ±10%, 1/2 W
R202	4700041	22K ohm, ±10%, 1/2 W
R203	4700041	22K ohm, ±10%, 1/2 W
R204	4700018	270 ohm, ±10%, 1/2 W
R205	4700018	680 ohm, ±10%, 1/2 W
R206	4700031	3.3K ohm, ±10%, 1/2 W
R207	4700037	10K ohm, ±10%, 1/2 W
R208	4700013	100 ohm, ±10%, 1/2 W
R209	4700047	68K ohm, ±10%, 1/2 W
R210	4700033	4.7K ohm, ±10%, 1/2 W
R211	4700016	180 ohm, ±10%, 1/2 W
R212	4700006	22 ohm, ±10%, 1/2 W
R213	4700031	3.3K ohm, ±10%, 1/2 W
R214	4700017	220 ohm, ±10%, 1/2 W
R215	4700006	22 ohm, ±10%, 1/2 W
R216	4700006	22 ohm, ±10%, 1/2 W
R217	4700017	4.7K ohm, ±10%, 1/2 W
R218	4700006	22 ohm, ±10%, 1/2 W
R219	4700006	22 ohm, ±10%, 1/2 W
R220	4700005	16 ohm, ±10%, 1/2 W
R221	4700025	2.2K ohm, ±10%, 1/2 W
R222	4700025	150 ohm, ±10%, 1/2 W

MARINE/MASTER-25w CHANNEL RECOMMENDATION CHART

INSTRUCTIONS

Your Marine/Master-25w automatically includes 3 channels. These channels are: Channel 6 (InterShip Safety), Channel 16 (Distress, Safety and Calling), and WX (Weather Service). All channels other than 6, 16, and WX which are in your Marine/Master-25w are called "working" channels.

In the event you wish to have additional channels installed in your Marine/Master-25w, utilize the following steps to determine which channels are recommended:

- Determine the total number of working channels that you will have in your Marine/Master-25w after you have installed the new channels.
 - Count any old working channels that are presently in your Marine/Master-25w, if any.
 - Don't include in your count channels 6, 16, or WX.
 - Add to this count the number of new working channels which you desire to install. This number determines the Total Number of Working Channels.
- If your ship is a recreational vessel locate the Total Number of Working Channels in column "A".
- If your ship is a commercial vessel locate the Total Number of Working Channels in column "B".
- Proceed down the column titled "Total Number of Working Channels" for your vessel and read across at each "x" for designation of communications recommended and the channel designation.
- Where more than one channel designation is listed, select the channel used in your boating area.

This manual is for educational purposes only. The accuracy and completeness of the information provided herein is not guaranteed or warranted. Genave shall not be liable for any loss or damages. Use at your own risk. Unauthorized reproduction is prohibited. Copyright © 2007 Genave/NRC, Inc., all rights reserved.

Ref. No.	Genave Part No.	Description
R223	4700003	10 ohm, ±10%, 1/2 W
R224	4700009	68 ohm, Wire Wound, ±10%, 1/2 W
R225	4700009	47 ohm, ±10%, 1/2 W
R226	4700009	47 ohm, ±10%, 1/2 W
R227		Unassigned
R228		Unassigned
R229		Unassigned
R230	4700045	47K ohm, ±10%, 1/2 W
R231	4700053	180K ohm, ±10%, 1/2 W
R232	4700053	220K ohm, ±10%, 1/2 W
R233	4700045	47K ohm, ±10%, 1/2 W
R234	4700015	150 ohm, ±10%, 1/2 W
R235	4700037	10K ohm, ±10%, 1/2 W
R236	4700035	6.8K ohm, ±10%, 1/2 W
R237	4700035	5.6K ohm, ±10%, 1/2 W
R238	4700034	5.6K ohm, ±10%, 1/2 W
R239	4760021	50K ohm, Variable Minipot, 20%
TC101	3136666	IC's
TC102	3136601	Silicon, TISN76666N
TC201	3130012	Silicon, Audio Output, 5N76001N Op. Amp, N5589V
TI101	5600080	TRANSFORMERS
TI102	5600080	Input, 1st IF
TI103	5600076	455 KHz
TI104	5600012	455 KHz IF, White Core
TI105	5600012	455 KHz IF, White Core
TI106	5600012	455 KHz IF, White Core
TI107	5600012	455 KHz IF, White Core
TI108	5600012	455 KHz IF, White Core
TI109	5600012	455 KHz IF, White Core
TI110	5600012	455 KHz IF, White Core
TI111	5600012	455 KHz IF, White Core
TI201	5600081	Osc
TI202	5600082	Tripler
TI203	5600083	1st Doubler
Y111	2300251	CRYSTALS
Y201	2300423	12.645 MHz
Y202	2300422	146.940 MHz, Xmit 146.940 MHz, RCV
Z101	1800035	CHOKES
Z201	1800063	1 microhenry, 200 series
Z202	1800063	Ferrox Cube Core Ferrox Cube Core
K201	4500007	MISCELLANEOUS
SW201	5100051	Relay, 4PDT, R10-E2-X4-V185 PB
SW202	5100052	Switch, Slide
	2502343	Switch, Push Button
	2502311	Button, Push
	2504712	Panel Front
	2502331	Panel Trim
	2502402	Knob
	2502282	Bracket Sub-Panel
	2502292	Bracket Transistor
	2502321	Bracket Mtg. (Handle)
	1325069	Cover
	1340408	Microphone (Ceramic) Speaker, 1.5 W, 8 ohm

FREQUENCY ERRATA

Channel 22CG is being redesignated 22A and is being utilized as a Coast Guard Marine Information Broadcast and Coast Guard communications frequency. After making contact with the Coast Guard on Channel 16 you may be asked to switch to Channel 22A for communicating. Channel 12 is being phased out as a Marine Information Broadcast Frequency.

	TOTAL NUMBER OF WORKING CHANNELS							TYPE OF COMMUNICATION	CHANNEL DESIGNATION							
	"A" Recreational Vessels															
	1	2	3	4	5	6	7	1	2	3	4	5	6	7		
	x	x	x	x	x	x	x	x	x	x	x	x	x	x	PORT OPERATIONS Ship/Ship & Ship/Coast	*22A(12)
								x							PORT OPERATIONS Ship/Ship & Ship/Coast	65, 66, 73, 80
								x							NAVIGATIONAL Ship/Ship & Ship/Coast	14, 74, 200
								x							ENVIRONMENTAL & WEATHER Ship Receive Only	13
								x							COMMERCIAL Ship/Ship & Ship/Coast	15, WX, 17
								x	x	x	x	x	x	x	COMMERCIAL Ship/Ship	7, 9, 10, 11, 12, 13, 14, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28, 29, 30, 31, 32, 33, 34, 35, 36, 37, 38, 39, 40, 41, 42, 43, 44, 45, 46, 47, 48, 49, 50, 51, 52, 53, 54, 55, 56, 57, 58, 59, 60, 61, 62, 63, 64, 65, 66, 67, 68, 69, 70, 71, 72, 73, 74, 75, 76, 77, 78, 79, 80, 81, 82, 83, 84, 85, 86, 87, 88, 89, 90, 91, 92, 93, 94, 95, 96, 97, 98, 99, 100
								x							NON-COMMERCIAL Ship/Ship & Ship/Coast	67, 8, 77, 88
								x	x	x	x	x	x	x	NON-COMMERCIAL Ship/Coast	68
								x	x	x	x	x	x	x	NON-COMMERCIAL Ship/Ship	9, 69, 71, 78
								x	x	x	x	x	x	x	NON-COMMERCIAL Ship/Ship	70, 72
								x	x	x	x	x	x	x	PUBLIC CORRESPONDENCE Ship/Public Coast	24, 84, 25, 85, 26, 86, 27, 87, 28

This manual is for educational purposes only. The accuracy and completeness of the information provided herein is not guaranteed or warranted. Genave shall not be liable for any loss or damages. Use at your own risk. Unauthorized reproduction is prohibited. Copyright © 2007 Genave/NRC, Inc., all rights reserved.


NUMERICAL LISTING OF VHF MARINE RADIOTELEPHONE CHANNELS

CHANNEL	XMIT FREQUENCY (MHz)	AUTHORIZED TRAFFIC	POINTS OF COMMUNICATION
1	156.050	International Only	Ship/Shore
2	156.100	International Only	Ship/Shore
3	156.150	International Only	Ship/Shore
4	156.200	International Only	Ship/Shore
5	156.250	International Only	Ship/Shore
6	156.300	INTERNATIONAL SAFETY	Ship/Shore
7	156.350	International Only	Ship/Shore
7A	156.350	Commercial	Ship/Shore
8	156.400	Commercial, Non-Commercial	Ship/Shore
9	156.450	Commercial	Ship/Shore
10	156.500	Commercial	Ship/Shore
11	156.550	Commercial	Ship/Shore
*12	156.600	Port Operations, USCG	Ship/Shore
13	156.650	Port Operations, USCG	Ship/Shore
14	156.650	Canals, Locks, Pilots	Ship/Shore
15	156.700	Port Operations, USCG	Ship/Shore
16	156.800	Environmental, Hydrographic	Ship/Shore
17	156.850	DISTRESS, SAFETY, & CALLING	Ship/Shore
18	156.900	Restricted, State Control	Ship/Shore
18A	156.900	Commercial	Ship/Shore
19	156.950	International Only	Ship/Shore
19A	156.950	Commercial	Ship/Shore
20	157.000	Port Operations	Ship/Shore
21	157.050	International Only	Ship/Shore
21CG	157.050	Restricted, USCG	Ship/Shore
22	157.100	International Only	Ship/Shore
*22A(CG)	157.100	Communications, USCG	Ship/Shore
23	157.150	International Only	Ship/Shore
23CG	157.150	Restricted, USCG	Ship/Shore
24	157.200	Public Correspondence	Ship/Shore
25	157.250	Public Correspondence	Ship/Shore
26	157.300	Public Correspondence	Ship/Shore
27	157.350	Public Correspondence	Ship/Shore
28	157.400	Public Correspondence	Ship/Shore
60	156.025	International Only	Ship/Ship, Ship/Shore
61	156.075	International Only	Ship/Ship, Ship/Shore
62	156.125	International Only	Ship/Ship, Ship/Shore
63	156.175	International Only	Ship/Ship, Ship/Shore
64	156.225	International Only	Ship/Ship, Ship/Shore
65	156.275	International Only	Ship/Ship, Ship/Shore
65A	156.275	Port Operations	Ship/Ship, Ship/Shore
66	156.325	International Only	Ship/Ship, Ship/Shore
66A	156.325	Port Operations	Ship/Ship, Ship/Shore
67	156.375	Commercial	Ship/Ship, Ship/Shore
68	156.425	Non Commercial	Ship/Ship, Ship/Shore
69	156.475	Non Commercial	Ship/Ship, Ship/Shore
70	156.525	Non Commercial	Ship/Ship, Ship/Shore
71	156.575	Non Commercial	Ship/Ship, Ship/Shore
72	156.625	Non Commercial	Ship/Ship, Ship/Shore
73	156.675	Port Operations	Ship/Ship, Ship/Shore
74	156.725	Port Operations	Ship/Ship, Ship/Shore
75	156.775	Port Operations	Ship/Ship, Ship/Shore
76	156.825	GUARD CHANNEL, unuseable	Ship/Ship, Ship/Shore
77	156.875	Commercial	Ship/Ship, Ship/Shore
78	156.925	International Only	Ship/Ship, Ship/Shore
78A	156.925	Non-Commercial	Ship/Ship, Ship/Shore
79	156.975	International Only	Ship/Ship, Ship/Shore
79A	156.975	Commercial	Ship/Ship, Ship/Shore
80	157.025	International Only	Ship/Ship, Ship/Shore
80A	157.025	Commercial	Ship/Ship, Ship/Shore
81	157.075	International Only	Ship/Ship, Ship/Shore
82	157.125	International Only	Ship/Ship, Ship/Shore
83	157.175	International Only	Ship/Ship, Ship/Shore
83CG	157.175	USCG Auxiliary Only	Ship/Ship, Ship/Shore
84	157.225	Public Correspondence	Ship/Ship, Ship/Shore
85	157.275	Public Correspondence	Ship/Ship, Ship/Shore
86	157.325	Public Correspondence	Ship/Ship, Ship/Shore
87	157.375	Public Correspondence	Ship/Ship, Ship/Shore
88	157.425	International Only	Ship/Ship, Ship/Shore
88A	157.425	Commercial	Ship/Ship, Ship/Shore
WX	162.550	Weather Broadcasts	Selected Coastal Stations
WX1	163.275	Weather Broadcasts	Selected Coastal Stations
WX2	163.400	Weather Broadcasts	Selected Coastal Stations

* See Frequency Errata, page 27.

NOTE: Authorizations and channels used may vary with locality. Check with local authorities for verification.

MarineMaster-25WA ADDENDUM



Specifications:

GENERAL:

- Front Panel Size: 6 1/2" x 2 1/2"
- Overall Dimensions: 9" deep x 6 1/2" wide x 2 1/2" high
- Number of Transistors: 12 transistors, 7 diodes, 6 FETs, 3 ICs
- Power Supply: 12 VDC, negative ground
- Frequency Range: 156 MHz to 162 MHz
- Channels Possible: 10
- Weight: Approx. 5 lbs.

RECEIVE:

- Sensitivity: .25 microvolt nom. for 12 db SINAD
- Image: .35 microvolt nom. for 20 db quieting more than 45 db down
- Spurious: more than 50 db down
- Selectivity: ±8 KHz
- Circuit: dual conversion, superheterodyne, crystal controlled
- Audio Output: 1.5 watts at less than 15% distortion
- Modulation Acceptance: more than 5 KHz
- Squelch Threshold: .35 microvolt, max.
- Adj. Channel Rejection: ±30 KHz, more than 65 db
- Current Drain: 2.0 amps

TRANSMIT:

- Frequency Range: 156 MHz to 158 MHz
- Power Output: 25 watts max.
- Output Impedance: matches standard VHF-FM marine antennas
- Current Drain: HI Pwr. 5.0 amps
Lo Pwr. 1.7 amps

GENERAL

With the exception of the ceramic piston trimmers for transmit frequency netting and the addition of the receiver preamplifier, the MarineMaster-25W/A is basically the same as the Marine/Master-25w.

INSTALLATION

Installation of the MarineMaster-25W/A is performed in the same manner as the Marine/Master-25w. All power and signal considerations remain the same.


OPERATING INSTRUCTIONS

Operating Instructions are the same as those described for the Marine/Master-25w.

ALIGNMENT PROCEDURE

Alignment is performed in the same manner as alignment for the Marine/Master-25w, with the addition of the Preamplifier Alignment. The alignment of the preamplifier is described in the preamplifier section.






MarineMaster-25WA
 Schematic
 Figure 7

This manual is for educational purposes only. The accuracy and completeness of the information provided herein is not guaranteed or warranted. Genave shall not be liable for any loss or damages. Use at your own risk. Unauthorized reproduction is prohibited. Copyright © 2007 Genave/NRC, Inc., all rights reserved.

MarineMaster-25WA
Parts/Track Map
Figure 8



This manual is for educational purposes only. The accuracy and completeness of the information provided herein is not guaranteed or warranted. Genave shall not be liable for any loss or damages. Use at your own risk. Unauthorized reproduction is prohibited. Copyright © 2007 Genave/NRC, Inc. All rights reserved.

MarineMaster-25WA PARTS LISI

MarineMaster-25WA PARTS LIST

This manual is for educational purposes only. The accuracy and completeness of the information provided herein is not guaranteed or warranted. Genave shall not be liable for any loss or damages. Use at your own risk. Unauthorized reproduction is prohibited. Copyright © 2007 Genave/NRC, Inc., all rights reserved.

Ref. No.	Genave Part No.	Description
CAPACITORS		
C101	1570120	Trimmer, 1.6 pf
C102	1510004	NPO Girmnick, .27 pf
C103	1570120	Trimmer, 1.6 pf
C104	1510003	NPO Girmnick, .22 pf
C105	1570120	Trimmer, 1.6 pf
C106	1520005	NPO Girmnick, 1.0 pf, 10%
C107	1510011	NPO Girmnick, 6.3 pf, 10%
C108	1520051	Y5U Disc, .01 mfd, 10%
C109	1520027	N750 Disc, 150 pf, 10%
C110	1520018	N220 Disc, 56 pf, 10%
C111	1520071	Disc, .001 mfd, 10%
C112	1520018	N220 Disc, 56 pf, 10%
C113	1520018	N220 Disc, 56 pf, 10%
C114	1520051	Y5U Disc, .01 mfd, 10%
C115	1520018	N220 Disc, 56 pf, 10%
C116	1520018	N220 Disc, 56 pf, 10%
C117	1520027	Unassigned
C118	1520027	N750 Disc, 150 pf, 10%
C119	1520175	NPO Disc, 7.5 pf
C120	1520175	NPO Disc, 7.5 pf
C121	1520054	M25 Disc, .05 mfd, 25V, +80-20%
C122	1520175	NPO Disc, 7.5 pf
C123	1520175	NPO Disc, 7.5 pf
C124	1520054	M25 Disc, .05 mfd, 25V, +80-20%
C125	1520054	M25 Disc, .05 mfd, 25V, +80-20%
C126	1520019	N330 Disc, 82 pf, 10%
C127	1520176	Disc, .001 mfd, 10%
C128	1520071	Disc, .001 mfd, 10%
C129	1540054	Aluminum Electrolytic, 10 mfd, 16V
C130	1520024	Y5E Disc, 470 pf, 10%
C131	1520022	Unassigned
C132	1520022	N220 Disc, 100 pf, 10%
C133	1520051	Y5U Disc, .01 mfd, 10%
C134	1520037	Y5E Disc, 330 pf, 10%
C135	1520037	Y5E Disc, 330 pf, 10%
C136	1520051	Y5U Disc, .01 mfd, 10%
C137	1540014	Aluminum Electrolytic, 10 mfd, 16V
C138	1500024	Mylar, .022 mfd, 10%, 100V
C139	1500079	Unassigned
C140	1550004	Z5U Disc, .005 mfd, 20%
C141	1500079	Par, 10 mfd, 25V, 10%
C142	1550005	Unassigned
C143	1550005	Par, 47 mfd, 15V, 10%
C144	1550004	PolyEthyle, .0015 mfd, 10%, 250V
C145	1540038	Aluminum Electrolytic, 2000 mfd, 30V
C146	1540212	Aluminum Electrolytic, 200 mfd, 12V
C147	1520176	N330 Disc, 82 pf, 10%
C148	1520007	NPO Disc, 10pf, 10%
C149	1520047	Y5E Disc, 820 pf, 10%
C150	1520176	N330 Disc, 82pf, 10%
C201	1520054	Unassigned
C202	1570121	M25 Disc, .05 mfd, 10%
C203	1570121	Trimmer, 5-25 pf
C204	1570121	Trimmer, 5-25 pf
C205	1570121	Trimmer, 5-25 pf
C206	1570121	Trimmer, 5-25 pf
C207	1570121	Trimmer, 5-25 pf
C208	1570121	Trimmer, 5-25 pf
C209	1570121	Trimmer, 5-25 pf
C210	1570121	Trimmer, 5-25 pf
C211	1570121	Trimmer, 5-25 pf
C212	1520022	N220 Disc, 100 pf, 10%
C213	1520022	N220 Disc, 100 pf, 10%
C214	1520022	N220 Disc, 100 pf, 10%
C215	1520071	Disc, .001 mfd, 10%
C216	1520071	Disc, .001 mfd, 10%
C217	1520071	Disc, .001 mfd, 10%
C218	1520071	Disc, .001 mfd, 10%
C219	1520051	N330 Disc, 82pf, 10%
C220	1520051	N330 Disc, 82pf, 10%
C221	1520027	N750 Disc, 150 pf, 10%
C222	1520027	N750 Disc, 150 pf, 10%
C223	1520027	N750 Disc, 150 pf, 10%
C224	1520027	N750 Disc, 150 pf, 10%
C225	1520027	N750 Disc, 150 pf, 10%
C226	1520027	N750 Disc, 150 pf, 10%
C227	1520027	N750 Disc, 150 pf, 10%
C228	1520027	N750 Disc, 150 pf, 10%
C229	1520027	N750 Disc, 150 pf, 10%
C230	1520027	N750 Disc, 150 pf, 10%
C231	1520027	N750 Disc, 150 pf, 10%
C232	1520027	N750 Disc, 150 pf, 10%
C233	1520027	N750 Disc, 150 pf, 10%
C234	1520027	N750 Disc, 150 pf, 10%
C235	1520027	N750 Disc, 150 pf, 10%
C236	1520027	N750 Disc, 150 pf, 10%
C237	1520027	N750 Disc, 150 pf, 10%
C238	1520027	N750 Disc, 150 pf, 10%
C239	1520027	N750 Disc, 150 pf, 10%
C240	1520027	N750 Disc, 150 pf, 10%
C241	1520027	N750 Disc, 150 pf, 10%
C242	1520027	N750 Disc, 150 pf, 10%
C243	1520027	N750 Disc, 150 pf, 10%
C244	1520027	N750 Disc, 150 pf, 10%
C245	1520027	N750 Disc, 150 pf, 10%
C246	1520027	N750 Disc, 150 pf, 10%
C247	1520027	N750 Disc, 150 pf, 10%
C248	1520027	N750 Disc, 150 pf, 10%
C249	1520027	N750 Disc, 150 pf, 10%
C250	1520027	N750 Disc, 150 pf, 10%
C251	1520027	N750 Disc, 150 pf, 10%
C252	1520027	N750 Disc, 150 pf, 10%
C253	1520027	N750 Disc, 150 pf, 10%
C254	1520027	N750 Disc, 150 pf, 10%
C255	1520027	N750 Disc, 150 pf, 10%
C256	1520027	N750 Disc, 150 pf, 10%
C257	1520027	N750 Disc, 150 pf, 10%
C258	1520027	N750 Disc, 150 pf, 10%
C259	1520027	N750 Disc, 150 pf, 10%
C260	1520027	N750 Disc, 150 pf, 10%
C261	1520027	N750 Disc, 150 pf, 10%
C262	1520027	N750 Disc, 150 pf, 10%
C263	1520027	N750 Disc, 150 pf, 10%
C264	1520027	N750 Disc, 150 pf, 10%
C265	1520027	N750 Disc, 150 pf, 10%
C266	1520027	N750 Disc, 150 pf, 10%
C267	1520027	N750 Disc, 150 pf, 10%
C268	1520027	N750 Disc, 150 pf, 10%
C269	1520027	N750 Disc, 150 pf, 10%
C270	1520027	N750 Disc, 150 pf, 10%
C271	1520027	N750 Disc, 150 pf, 10%
C272	1520027	N750 Disc, 150 pf, 10%
C273	1520027	N750 Disc, 150 pf, 10%
C274	1520027	N750 Disc, 150 pf, 10%
C275	1520027	N750 Disc, 150 pf, 10%
C276	1520027	N750 Disc, 150 pf, 10%
C277	1520027	N750 Disc, 150 pf, 10%
C278	1520027	N750 Disc, 150 pf, 10%
C279	1520027	N750 Disc, 150 pf, 10%
C280	1520027	N750 Disc, 150 pf, 10%
C281	1520027	N750 Disc, 150 pf, 10%
C282	1520027	N750 Disc, 150 pf, 10%
C283	1520027	N750 Disc, 150 pf, 10%
C284	1520027	N750 Disc, 150 pf, 10%
C285	1520027	N750 Disc, 150 pf, 10%
C286	1520027	N750 Disc, 150 pf, 10%
C287	1520027	N750 Disc, 150 pf, 10%
C288	1520027	N750 Disc, 150 pf, 10%
C289	1520027	N750 Disc, 150 pf, 10%
C290	1520027	N750 Disc, 150 pf, 10%
C291	1520027	N750 Disc, 150 pf, 10%
C292	1520027	N750 Disc, 150 pf, 10%
C293	1520027	N750 Disc, 150 pf, 10%
C294	1520027	N750 Disc, 150 pf, 10%
C295	1520027	N750 Disc, 150 pf, 10%
C296	1520027	N750 Disc, 150 pf, 10%
C297	1520027	N750 Disc, 150 pf, 10%
C298	1520027	N750 Disc, 150 pf, 10%
C299	1520027	N750 Disc, 150 pf, 10%
C300	1520027	N750 Disc, 150 pf, 10%
C301	1520027	N750 Disc, 150 pf, 10%
C302	1520027	N750 Disc, 150 pf, 10%
C303	1520027	N750 Disc, 150 pf, 10%
C304	1520027	N750 Disc, 150 pf, 10%
C305	1520027	N750 Disc, 150 pf, 10%
C306	1520027	N750 Disc, 150 pf, 10%
C307	1520027	N750 Disc, 150 pf, 10%
C308	1520027	N750 Disc, 150 pf, 10%
C309	1520027	N750 Disc, 150 pf, 10%
C310	1520027	N750 Disc, 150 pf, 10%
C311	1520027	N750 Disc, 150 pf, 10%
C312	1520027	N750 Disc, 150 pf, 10%
C313	1520027	N750 Disc, 150 pf, 10%
C314	1520027	N750 Disc, 150 pf, 10%
C315	1520027	N750 Disc, 150 pf, 10%
C316	1520027	N750 Disc, 150 pf, 10%
C317	1520027	N750 Disc, 150 pf, 10%
C318	1520027	N750 Disc, 150 pf, 10%
C319	1520027	N750 Disc, 150 pf, 10%
C320	1520027	N750 Disc, 150 pf, 10%
C321	1520027	N750 Disc, 150 pf, 10%
C322	1520027	N750 Disc, 150 pf, 10%
C323	1520027	N750 Disc, 150 pf, 10%
C324	1520027	N750 Disc, 150 pf, 10%
C325	1520027	N750 Disc, 150 pf, 10%
C326	1520027	N750 Disc, 150 pf, 10%
C327	1520027	N750 Disc, 150 pf, 10%
C328	1520027	N750 Disc, 150 pf, 10%
C329	1520027	N750 Disc, 150 pf, 10%
C330	1520027	N750 Disc, 150 pf, 10%
C331	1520027	N750 Disc, 150 pf, 10%
C332	1520027	N750 Disc, 150 pf, 10%
C333	1520027	N750 Disc, 150 pf, 10%
C334	1520027	N750 Disc, 150 pf, 10%
C335	1520027	N750 Disc, 150 pf, 10%
C336	1520027	N750 Disc, 150 pf, 10%
C337	1520027	N750 Disc, 150 pf, 10%
C338	1520027	N750 Disc, 150 pf, 10%
C339	1520027	N750 Disc, 150 pf, 10%
C340	1520027	N750 Disc, 150 pf, 10%
C341	1520027	N750 Disc, 150 pf, 10%
C342	1520027	N750 Disc, 150 pf, 10%
C343	1520027	N750 Disc, 150 pf, 10%
C344	1520027	N750 Disc, 150 pf, 10%
C345	1520027	N750 Disc, 150 pf, 10%
C346	1520027	N750 Disc, 150 pf, 10%
C347	1520027	N750 Disc, 150 pf, 10%
C348	1520027	N750 Disc, 150 pf, 10%
C349	1520027	N750 Disc, 150 pf, 10%
C350	1520027	N750 Disc, 150 pf, 10%
C351	1520027	N750 Disc, 150 pf, 10%
C352	1520027	N750 Disc, 150 pf, 10%
C353	1520027	N750 Disc, 150 pf, 10%
C354	1520027	N750 Disc, 150 pf, 10%
C355	1520027	N750 Disc, 150 pf, 10%
C356	1520027	N750 Disc, 150 pf, 10%
C357	1520027	N750 Disc, 150 pf, 10%
C358	1520027	N750 Disc, 150 pf, 10%
C359	1520027	N750 Disc, 150 pf, 10%
C360	1520027	N750 Disc, 150 pf, 10%
C361	1520027	N750 Disc, 150 pf, 10%
C362	1520027	N750 Disc, 150 pf, 10%
C363	1520027	N750 Disc, 150 pf, 10%
C364	1520027	N750 Disc, 150 pf, 10%
C365	1520027	N750 Disc, 150 pf, 10%
C366	1520027	N750 Disc, 150 pf, 10%
C367	1520027	N750 Disc, 150 pf, 10%
C368	1520027	N750 Disc, 150 pf, 10%
C369	1520027	N750 Disc, 150 pf, 10%
C370	1520027	N750 Disc, 150 pf, 10%
C371	1520027	N750 Disc, 150 pf, 10%
C372	1520027	N750 Disc, 150 pf, 10%
C373	1520027	N750 Disc, 150 pf, 10%
C374	1520027	N750 Disc, 150 pf, 10%
C375	1520027	N750 Disc, 150 pf, 10%
C376	1520027	N750 Disc, 150 pf, 10%
C377	1520027	N750 Disc, 150 pf, 10%
C378	1520027	N750 Disc, 150 pf, 10%
C379	1520027	N750 Disc, 150 pf, 10%
C380	1520027	N750 Disc, 150 pf, 10%
C381	1520027	N750 Disc, 150 pf, 10%
C382	1520027	N750 Disc, 150 pf, 10%
C383	1520027	N750 Disc, 150 pf, 10%
C384	1520027	N750 Disc, 150 pf, 10%
C385	1520027	N750 Disc, 150 pf, 10%
C386	1520027	N750 Disc, 150 pf, 10%
C387	1520027	N750 Disc, 150 pf, 10%
C388	1520027	N750 Disc, 150 pf, 10%
C389	1520027	N750 Disc, 150 pf, 10%
C390	1520027	N750 Disc, 150 pf, 10%
C391	1520027	N750 Disc, 150 pf, 10%
C392	1520027	N750 Disc, 150 pf, 10%
C393	1520027	N750 Disc, 150 pf, 10%
C394	1520027	N750 Disc, 150 pf, 10%
C395	1520027	N750 Disc, 150 pf, 10%
C396	1520027	N750 Disc, 150 pf, 10%
C397	1520027	N750 Disc, 150 pf, 10%
C398	1520027	N750 Disc, 150 pf, 10%
C399	1520027	N750 Disc, 150 pf, 10%
C400		

MarineMaster-25WA PARTS LIST

This manual is for educational purposes only. The accuracy and completeness of the information provided herein is not guaranteed or warranted. Genave shall not be liable for any loss or damages. Use at your own risk. Unauthorized reproduction is prohibited. Copyright © 2007 Genave/NRC, Inc., all rights reserved.

Ref. No.	Genave Part No.	Description
C239	1560403	Trimmer, 40 pf
C231	1520071	Disc, .001 mfd, 10%
C232	1520071	Disc, .001 mfd, 10%
C233	1560403	Disc, .001 mfd, 10%
C234	1560403	Disc, .001 mfd, 10%
C235	1520013	Trimmer, 40 pf
C236	1520013	Trimmer, 40 pf
C237	1520042	NPO Disc, 33 pf, 10%
C238	1540002	Y5E Disc, 470 pf, 10%
C239	1560406	Aluminum Electrolytic, 1 mfd, 40V
C240	1520054	Aluminum Electrolytic, 1 mfd, 40V
C241	1520071	Trimmer, 115 pf
C242	1520022	M25 Disc, .05 mfd, 10%
C243	1560406	Disc, .001 mfd, 10%
C244	1520054	M25 Disc, .05 mfd, 10%
C245	1520071	Trimmer, 115 pf
C246	1520176	Disc, .001 mfd, 10%
C247	1560406	N330 Disc, 82 pf, 10%
C248	1560406	Trimmer, 115 pf
C249	1520011	NPO Disc, 22 pf, 10%
C250	1520011	NPO Disc, 22 pf, 10%
C251	1520011	NPO Disc, 22 pf, 10%
C252	1520011	NPO Disc, 22 pf, 10%
C253	1520011	NPO Disc, 22 pf, 10%
C254	1520011	NPO Disc, 22 pf, 10%
C255	1520022	N220 Disc, 100 pf, 10%
C256	1540002	Aluminum Electrolytic, 1 mfd, 40V
C257	1520028	Y5E Disc, 150 pf, 10%
C258	1540014	Aluminum Electrolytic, 10 mfd
C259	1520028	Y5E Disc, 150 pf, 10%
C260	1520053	M25 Disc, .02 mfd, 10%
C261	1500079	Unassigned
C262	1520028	Mylar, .005 mfd, ±20%
C263	1520028	Y5E Disc, 150 pf, 10%
C264	1520028	Mylar, .0047 mfd, 100V, 10%
C265	1520028	Y5E Disc, 150 pf, 10%
C266	1500079	Mylar, .005 mfd, ±20%
C267	1540002	Aluminum Electrolytic, 1 mfd, 40V
C268	1520054	M25 Disc, .05 mfd, 10%
C269	1520054	M25 Disc, .05 mfd, 10%
C270	1510014	NFO Disc, 1.8 pf, 10%
C271	1520037	Y5E Disc, 330 pf, 10%
C272	1520022	N220 Disc, 100 pf, 10%
C273	1520010	Unassigned
C274	1520010	NPO Disc, 18 pf, 10%
C275	1520010	NPO Disc, 18 pf, 10%
C276	1520010	NPO Disc, 18 pf, 10%
C277	1520010	NPO Disc, 18 pf, 10%
C278	1520010	NPO Disc, 18 pf, 10%
C279	1520010	NPO Disc, 18 pf, 10%
C280	1520010	NPO Disc, 18 pf, 10%
C281	1520010	NPO Disc, 18 pf, 10%
C282	1520010	NPO Disc, 18 pf, 10%
C283	1520010	NPO Disc, 18 pf, 10%
CR101	4810021	IN34A, Germanium
CR102	4810021	IN34A, Germanium
CR201	4810007	Zener, 6.8V, ±10%
CR202	4812109	Varicap, MV2109 or SKV1638
CR203	4810013	Gen. Purpore, 100V, @ 1 amp
CR204	4810013	Gen. Purpore, 100V, @ 1 amp
CR205	4810013	Gen. Purpore, 100V, @ 1 amp
CR206	4810007	Zener, 6.8V, ±10%
DS101	3900025	Clear, 14V, #53
DS102	3900025	Clear, 14V, #53
DS201	3900025	Clear, 14V, #53
L101	1800106	Coil, Input
L102	1800107	Coil, Center Pole Input Filter
L103	1800108	Coil, Output
L104	1800200	Coil, Osc.
L201	1800203	Coil, Transmitter
L202	1800201	Coil, Transmitter
L203	1800201	Coil, Transmitter
L204	1800202	Coil, Transmitter
L205	1800201	Coil, Transmitter

DIODES

LAMPS

COILS



This manual is for educational purposes only. The accuracy and completeness of the information provided herein is not guaranteed or warranted. Genave shall not be liable for any loss or damages. Use at your own risk. Unauthorized reproduction is prohibited. Copyright © 2007 Genave/NRC, Inc. All rights reserved.

MarineMaster-25WA PARTS LIST

This manual is for educational purposes only. The accuracy and completeness of the information provided herein is not guaranteed or warranted. Genave shall not be liable for any loss or damages. Use at your own risk. Unauthorized reproduction is prohibited. Copyright © 2007 Genave/NRC, Inc., all rights reserved.

Ref. No.	Genave Part No.	Description
C230	1560403	Trimmer, 40 pf
C231	1520071	Disc, .001 mfd, 10%
C232		Unassigned
C233	1520071	Disc, .001 mfd, 10%
C234	1560403	Trimmer, 40 pf
C235	1560403	Trimmer, 40 pf
C236	1520013	NPO Disc, 33 pf, 10%
C237	1520042	YSE Disc, 470 pf, 10%
C238	1520002	Aluminum Electrolytic, 1 mfd, 40V
C239	1560406	Trimmer, 115 pf
C240	1520054	M25 Disc, .05 mfd, 10%
C241	1520071	Disc, .001 mfd, 10%
C242	1520022	N220 Disc, 100 pf, 10%
C243	1520022	Trimmer, 115 pf
C244	1520094	M25 Disc, .05 mfd, 10%
C245	1520071	Disc, .001 mfd, 10%
C246	1520176	N330 Disc, 82 pf, 10%
C247	1520176	Trimmer, 115 pf
C248	1560406	NPO Disc, 22 pf, 10%
C249	1520011	NPO Disc, 22 pf, 10%
C250	1520011	NPO Disc, 22 pf, 10%
C251	1520011	NPO Disc, 22 pf, 10%
C252	1520011	NPO Disc, 22 pf, 10%
C253	1520011	NPO Disc, 22 pf, 10%
C254	1520011	NPO Disc, 22 pf, 10%
C255	1520022	N220 Disc, 100 pf, 10%
C256	1540002	Aluminum Electrolytic, 1 mfd, 40V
C257	1520028	YSE Disc, 150 pf, 10%
C258	1540014	Aluminum Electrolytic, 10 mfd
C259	1520028	YSE Disc, 150 pf, 10%
C260	1520053	M25 Disc, .02 mfd, 10%
C261		Unassigned
C262	1500079	WVlar, .005 mfd, ±20%
C263	1520028	YSE Disc, 150 pf, 10%
C264	1500013	WVlar, .0047 mfd, 100V, 10%
C265	1520028	YSE Disc, 150 pf, 10%
C266	1500079	WVlar, .005 mfd, ±20%
C267	1540002	Aluminum Electrolytic, 1 mfd, 40V
C268	1520054	M25 Disc, .05 mfd, 10%
C269	1520054	M25 Disc, .05 mfd, 10%
C270	1510014	NPO Disc, 1.8 pf, 10%
C271	1520037	YSE Disc, 330 pf, 10%
C272	1520022	N220 Disc, 100 pf, 10%
C273		Unassigned
C274	1520010	NPO Disc, 18 pf, 10%
C275	1520010	NPO Disc, 18 pf, 10%
C276	1520010	NPO Disc, 18 pf, 10%
C277	1520010	NPO Disc, 18 pf, 10%
C278	1520010	NPO Disc, 18 pf, 10%
C279	1520010	NPO Disc, 18 pf, 10%
C280	1520010	NPO Disc, 18 pf, 10%
C281	1520010	NPO Disc, 18 pf, 10%
C282	1520010	NPO Disc, 18 pf, 10%
C283	1520010	NPO Disc, 18 pf, 10%
DIODES		
CR101	4810021	IN34A, Germanium
CR102	4810021	IN34A, Germanium
CR201	4810007	Zener, 6.8V, ±10%
CR202	4812109	Varicap, MV21020 @ SKV1638
CR203	4810013	Gen. Purpose, 100V, @ 1 amp
CR204	4810013	Gen. Purpose, 100V, @ 1 amp
CR205	4810013	Gen. Purpose, 100V, @ 1 amp
CR206	4810007	Zener, 6.8V, ±10%
LAMPS		
DS101	3900025	Clear, 14V, #53
DS102	3900025	Clear, 14V, #53
DS201	3900025	Clear, 14V, #53
COILS		
L101	1800106	Coil, Input
L102	1800107	Coil, Center Pole Input Filter
L103	1800108	Coil, Output
L104	1800200	Coil, Osc.
L201	1800203	Coil, Transmitter
L202	1800201	Coil, Transmitter
L203	1800201	Coil, Transmitter
L204	1800202	Coil, Transmitter
L205	1800201	Coil, Transmitter



This manual is for educational purposes only. The accuracy and completeness of the information provided herein is not guaranteed or warranted. Genave shall not be liable for any loss or damages. Use at your own risk. Unauthorized reproduction is prohibited. Copyright © 2007 Genave/NRC, Inc. All rights reserved.

MarineMaster-25WA PARTS LIST

MarineMaster-25WA

DC VOLTAGE MEASUREMENTS

All voltages shown in this table were measured with a VTVM from chassis ground. The DC input to the radio should be set to 13.75 VDC. The squelch control should be in the full off position and the volume control in the minimum position. No signal should be applied. The receiver A+ line should measure 13.0 VDC. A variation of $\pm 20\%$ of the measured voltages from those listed may be considered normal.

Ref. No.	E	B	C	or	D	S	G	H
Q101	1.8	2.4	12.4					
Q101					12.4	0	0	
Q102					11.0	0	0	5.9
Q103					11.0	0	0	
Q104					11.6	0	0	
Q105					11.6	0	0	
Q106		6.2		0				
Q107		0.6	2.8					
Q109		0	0.47	5.8				
Q110		0	0.42	5.8				
Q111		0	7.2	6.8				
Q201 (Recv)		6.5						
Q201 (Xmit)		0	0					
Pin 1	2	3	4	5	6	7	8	9
IC101	2.0	2.0	0	11.5	—	5.6	4.8	4.1
IC102	12.8	—	7.7	0.8	0.6	—	0	0
								—
								6.5
								5.8
								12.9

MarineMaster-25WA

RECEIVER SENSITIVITY & GAIN MEASUREMENTS

Frequency	Input Point	Measurement Point	Measured Value
156.3 MHz	Ant. Conn.	Across Speaker	— 115 dbm or better for 20 db quieting
13.1 MHz	Tap L103	Sec. T110	500 uv or less for 0.3 V P-P (Scope)
13.1 MHz	Pin 3 T102	Pri. T104	45 mv for 0.3 V P-P (Scope)
13.1 MHz	Pin 3 T102	Source Q104	11 mv for 0.3 V P-P (Scope)
13.1 MHz	Pin 3 T102	Drain Q104	13 mv for 0.3 V P-P (Scope)
13.1 MHz	Pin 3 T102	Pri. T106	23 mv for 0.3 V P-P (Scope)
13.1 MHz	Pin 3 T102	Source Q105	3.4 mv for 0.3 V P-P (Scope)
13.1 MHz	Pin 3 T102	Drain Q105	5.5 mv for 0.3 V P-P (Scope)
13.1 MHz	Pin 3 T102	Pri. T108	10 mv for 0.3 V P-P (Scope)
13.1 MHz	Pin 3 T102	Source Q106	1.5 mv for 0.3 V P-P (Scope)
13.1 MHz	Pin 3 T102	Drain Q106	1.5 mv for 0.3 V P-P (Scope)
13.1 MHz	Pin 3 T102	Pri. T110	3 mv for 0.3 V P-P (Scope)
156.3 MHz	Ant. Conn.	Across Speaker	2 uv or better for 1 watt output, 400 to 3000 Hz.

Ref. No.	Genave Part No.	Description
R213	4700031	3.3K ohm, $\pm 10\%$, $\frac{1}{2}W$
R214	4700017	220 ohm, $\pm 10\%$, $\frac{1}{2}W$
R215	4700006	22 ohm, $\pm 10\%$, $\frac{1}{2}W$
R216	4700006	22 ohm, $\pm 10\%$, $\frac{1}{2}W$
R217	4700032	4.7K ohm, $\pm 10\%$, $\frac{1}{2}W$
R218	4700012	220 ohm, $\pm 10\%$, $\frac{1}{2}W$
R219	4700006	22 ohm, $\pm 10\%$, $\frac{1}{2}W$
R220	4700006	22 ohm, $\pm 10\%$, $\frac{1}{2}W$
R221	4700029	2.2K ohm, $\pm 10\%$, $\frac{1}{2}W$
R222	4700015	150 ohm, $\pm 10\%$, $\frac{1}{2}W$
R223	4700003	10 ohm, $\pm 10\%$, $\frac{1}{2}W$
R224	4720079	47 ohm, $\pm 10\%$, $\frac{1}{2}W$
R225	4700009	47 ohm, $\pm 10\%$, $\frac{1}{2}W$
R226	4700009	47 ohm, $\pm 10\%$, $\frac{1}{2}W$
R227	Unassigned	Unassigned
R228	Unassigned	Unassigned
R229	Unassigned	Unassigned
R230	4700045	47K ohm, $\pm 10\%$, $\frac{1}{2}W$
R231	4700052	180K ohm, $\pm 10\%$, $\frac{1}{2}W$
R232	4700053	220K ohm, $\pm 10\%$, $\frac{1}{2}W$
R233	4700045	47K ohm, $\pm 10\%$, $\frac{1}{2}W$
R234	4700015	150 ohm, $\pm 10\%$, $\frac{1}{2}W$
R235	4700037	10K ohm, $\pm 10\%$, $\frac{1}{2}W$
R236	4700035	6.8K ohm, $\pm 10\%$, $\frac{1}{2}W$
R237	4700043	33K ohm, $\pm 10\%$, $\frac{1}{2}W$
R238	4700034	56K ohm, $\pm 10\%$, $\frac{1}{2}W$
R239	4760021	50K ohm, Variable, Minipot, 20%
R240	4700024	820 ohm, $\pm 10\%$, $\frac{1}{2}W$
R253	4700015	150 ohm, $\pm 10\%$, $\frac{1}{2}W$
INTEGRATED CIRCUITS		
IC101	3136666	Silicon, TISN 76666N
IC102	3136601	Silicon, Audio Output, 5N76001N
IC201	3130012	Op. Amp., N5558V
TRANSFORMERS		
T101	5600080	Input, 1st IF
T102	5600076	Input, 1st IF
T103	5600012	455 KHz
T104	5600012	455 KHz IF, White Core
T105	5600012	455 KHz IF, White Core
T106	5600012	455 KHz IF, White Core
T107	5600012	455 KHz IF, White Core
T108	5600012	455 KHz IF, White Core
T109	5600012	455 KHz IF, White Core
T110	5600012	455 KHz IF, White Core
T111	5600081	455 KHz IF, White Core
T201	5600082	Osc
T202	5600082	Tripler
T203	5600083	1st Doubler
CRYSTALS		
Y101	2300268	47.7333333 MHz, RCV
Y102	2300324	47.9000000 MHz, RCV
Y110	2300324	49.816667 MHz, RCV
Y111	2300251	12.645 MHz
Y201	2300167	13.025000 MHz, Xmit
Y202	2300185	13.066667 MHz, Xmit
CHOKES		
Z101	1800035	1 microhenry, 200 series
Z201	1800063	Ferrox Cube Core
Z202	1800063	Ferrox Cube Core
MISCELLANEOUS		
K201	4500007	Relay, 4PDT
SW201	5100051	Switch, Slide
SW202	5100052	Panel, Pushbutton
	2502311	Panel Front
	2509121	Panel Trim
	2508401	Knob Vol. & Sq.
	2502402	Bracket Sub-Panel
	2502292	Bracket Mtg. (Handle)
	2502621	Cover
	1325069	Microphone (ceramic)
	1320408	Speaker, 1.5W, 8 ohm

This manual is for educational purposes only. The accuracy and completeness of the information provided herein is not guaranteed or warranted. Genave shall not be liable for any loss or damages. Use at your own risk. Unauthorized reproduction is prohibited. Copyright © 2007 Genave/NRC, Inc., all rights reserved.

This manual is for educational purposes only. The accuracy and completeness of the information provided herein is not guaranteed or warranted. Genave shall not be liable for any loss or damages. Use at your own risk. Unauthorized reproduction is prohibited. Copyright © 2007 Genave/NRC, Inc., all rights reserved.

TECHNICAL BULLETIN

GENERAL
AVIATION
ELECTRONICS
INC.



4141 KINGMAN DRIVE
INDIANAPOLIS, IND. 46226
AREA 317 • 546-1111

TB 7404

28 August 1974

SUBJECT: Marine/Mate-10A, Marine/Mate-100, Marine/Master-25W
and Marine/Master-25W/A Maintenance Manual Update

The information contained here is intended to update the data published in the Marine/Mate-10A, Marine/Mate-100, Marine/Master-25W and Marine/Master-25W/A Maintenance Manuals.

- 1) Change the Marine/Mate-10A, Marine/Mate-100, Marine/Master-25W and Marine/Master-25W/A Parts Lists to read as follows:

R136 Selected Value (Nominal P/N 4700037, 10K, 10%, 1/2W)



TECHNICAL BULLETIN

TB7301

PRELIMINARY

11 June, 1973



4141 KINGMAN DRIVE
INDIANAPOLIS, IND. 46226
AREA 317 • 546-1113

The following information is intended as a troubleshooting aid and update for Genave FM transceivers. The maintenance manuals for the various products will reflect the updated information. Please keep this information on hand along with previous material sent to you on our FM products.

1. On Genave FM equipment with push-button channel selectors, problems involving starting different numbers of crystals arise from the changing base to ground capacitance on Q201. As more crystals are added this capacitance increases. It must be compensated by changing the network containing C213 and C214. The current production value of C213 is 56 pfd and C214 is 82 pfd. As additional crystals are installed, C214 must be increased. This is accomplished by paralleling 100 to 150 pfd (N750 type or better) across C214 on the bottom of the board.

2. Difficulties have developed in the field with Genave FM units utilizing a rotary channel selector switch, especially when crystals are added. The symptoms are transmit and receive instability caused by long connecting wires in the circuit. All current production models employ a modified circuit which eliminates this problem. Genave will attempt same day service on all radios sent to us with the old circuit.

3. The transmit oscillator will also fail if its associated zener regulator is not operating. Check for 6.8 volts nominal on the collector of Q201.

4. Relative to amateur radios only: Installation of '52' receive crystals may produce a quieting effect on the receiver. The cause is off-frequency second L.O. crystals, which have a spur or harmonic falling on the receive frequency. Replace crystals (p/n 2300251) which are more than 1 khz off 12.645 Mhz. Y111 is the affected part and is a soldered-in part which will be replaced if returned to Genave.

5. Genave FM radiotelephones have two 6.8 volt zener regulated supplies. One supply is on constantly, running the modulator. The other is switched on and off by the 13.75 volt transmit line and powers the transmit oscillator. This means that R203 is always tied to ground, biasing Q201, and oscillation is no longer stopped by saturation of Q201 but by cutting its supply voltage. Typical operating voltages for Q201 are: Emitter 2.7 v, Base 3.4 v, Collector 6.8 v.

6. Typical operating voltages for the modulator op amp IC201 are: pin 8-6.8 v, pins 7,6,5,3,2,1-3.2 v, pin 4-0 v.

7. Here is an aid for troubleshooting low power, after performing the alignment procedure in the manual.

a.) To determine whether the problem exists in the final output stage or a previous stage perform the following test;

1) Connect the unit to a 13.75 v regulated supply, and a suitable load to its output.

2) Switch the radio to the 1 watt position.


3) Key the transmitter and measure the dc voltage from the collector of Q206 to ground.

4) If this voltage is less than 3.5 v but greater than .5 v the problem most likely exists with the final output stage.

5) An rf voltage probe will usually read 20 volts or more from the collector of Q207 if the device is working to specs. It may be assumed that if this voltage is present that the loss is in the output tuning and filter section.

b.) When replacing the output device also replace all associated capacitors on the bottom of the board in the positions they were installed.

GENERAL
AVIATION
ELECTRONICS
INC.



4141 KINGMAN DRIVE
INDIANAPOLIS, IND. 46226
AREA 317 • 546-1111

TB7407

October 29, 1974

SUBJECT: Transmitter Class C Doubler failures
in GTX-2, GTX-10, GTX-200, Marine/
Master-25WA, Marine Mate-10A, Marine
Mate-100, and Mobiline I transceivers.

As a result of a few reported field failures of the Class C Doubler stage in the above transceivers, the MPS6511 transistor is being replaced in all new transceivers with a 2N4427 transistor, equipped with a ferrite bead on the collector lead.

If, as the result of a field failure, it is necessary to replace any of the following transistors, replace it with the 2N4427 and ferrite bead.

Q203 in GTX-2, GTX-10, GTX-200, Marine/Master-25WA, Marine Mate-10A, and Marine Mate-100.

Q204 in Mobiline I

The new replacement parts are available in new FM Parts Kits or by ordering from the factory. The corresponding part numbers are as follows:

P/N 4804427	Silicon, NPN, 2N4427
P/N 1870004	Ferrite Bead, Stackpole #57-1362

Install the new parts as shown:

